



Fischer Panda

Power - wherever you are



Manual marine generator
Panda PMS AGT-DC 8000

12V-72V DC / 8 kVA

Panda PMS AGT-DC 10000

12V-72V DC / 10 kVA

Fischer Panda GmbH



Current revision status

	Document
Actual:	Panda_AGT-DC_8000-10000_PMS_12-72V_eng_.R01_18.2.11
Replace:	

Revision	Page

Erstellt durch / created by

Fischer Panda GmbH - Leiter Technische Dokumentation

Otto-Hahn-Str. 32-34

33104 Paderborn - Germany

Tel.: +49 (0) 5254-9202-0

email: info@fischerpanda.de

web: www.fischerpanda.de

Copyright

Duplication and change of the manual is permitted only in consultation with the manufacturer!

Fischer Panda GmbH, 33104 Paderborn, reserves all rights regarding text and graphics. Details are given to the best of our knowledge. No liability is accepted for correctness. Technical modifications for improving the product without previous notice may be undertaken without notice. Before installation, it must be ensured that the pictures, diagrams and related material are applicable



Inhalt / Contents

1	Special notes and safety instructions for AGT- Generators.....	9
1.1	General safety references concerning operation of an AGT generator.	9
1.1.1	Cooling of the rectifier block at the marine versions	9
1.2	Sample System AGT DC Generator	9
1.2.1	Measures to the fire protection.	11
1.3	Special Tools	11
2	General References and Regulations	13
2.1	Safety first symbols	14
2.2	Tools	19
2.3	Manufacturer declaration in accordance with the machine guideline 98/37/EG	21
2.4	Customer registration and guarantee	21
2.4.1	Technical Support	21
2.4.2	Attention, important directions regarding operation!	21
2.5	Safety instructions - Safety first!	22
2.5.1	Safe operation	22
2.5.2	Observe safety instructions	22
2.5.3	Wear personal protective equipment (PPE)	22
2.5.4	Cleanness protect	22
2.5.5	Safe handling of fuel and lubricants - Keep away from fire	23
2.5.6	Exhaust gases and fire prevention	23
2.5.7	Cautions against burns and battery explosion	24
2.5.8	Keep hands away from rotating parts	24
2.5.9	Anti-Freeze and disposal of fluids	24
2.5.10	Implementation of security and maintenance	25
2.6	Warning and caution labels	25
2.6.1	Safety instructions concerning operating the generator	25
2.6.1.1	Protective grounding and potential equalisation.....	26
2.6.1.2	Ground wire.....	26
2.6.1.3	Switch off all load when working on the generator.....	26
2.6.1.4	Safety instructions concerning the cables.....	27
2.6.2	Recommended starter battery size	27
2.6.3	Important Advice for Batteries - Starting batteries and Traction batteries	27
2.6.4	Safety Instructions for the Handling with Batteries	28
3	Basics	31
3.0.1	Intended use of the maschine	31
3.0.2	Purpose of the manual und description of the definitions trained person/operator/user ...	31
3.0.2.1	Trained persons	31
3.0.3	Operator	31
3.0.3.1	User.....	31
3.1	Panda Transport Box	32
3.1.1	Bolted Fischer Panda Transport Box	32
3.1.2	Fischer Panda Transport Box with metal tab closure	32
3.2	Transport and Loading/Unloading	32
3.2.1	Transporting the generator	32
3.2.2	Loading/unloading of the generator	32
3.3	Scope of delivery	33
3.3.1	PM generator:	33
3.4	Opening the MPL sound insulation capsule	35
3.4.1	Opening the GFK sound insulation capsule	36



Inhalt / Contents

3.5	Special maintenance notes and arrangements at long periods of stand still time or shut-down	36
3.5.1	Reference note for the starter battery at a long-term standstill	37
3.5.2	Arrangements at a short-term standstill	37
3.5.3	Arrangements at a medium-term standstill / winter storage	37
3.5.3.1	Arrangements for conservation:.....	37
3.5.3.2	Arrangements for deconservation after a medium-term standstill (3 to 6 months).....	38
3.5.4	Arrangements at a long-term standstill / shutdown	39
3.5.4.1	Arrangements for conservation:.....	39
3.5.4.2	Arrangements after a long-term standstill (shutdown) / recommissioning (more than 6 months):	40
4	The Panda Generator	41
4.1.1	Right Side View	41
4.1.2	Left Side View	42
4.1.3	Front View	43
4.1.4	Back View	44
4.1.5	View from Above	45
4.2.1	Control panel	46
4.2.2	The cooling system (Fresh and raw water)	47
4.2.3	The fuel and air system	48
4.2.4	The electrical system	49
4.2.5	Sensors and switches for operating surveillance	51
4.2.6	The oil circuit	54
4.2.7	External components	55
5	Installation Instructions	57
5.1	Personal requirements	57
5.1.1	Hazard notes for the installation	57
5.2	Placement	58
5.2.1	Advice for optimal sound insulation	59
5.3	Generator Connections	59
5.4	Cooling System Installation - Raw Water	59
5.4.1	General Information	59
5.4.2	Installation of the thru hull fitting in Yachts	60
5.4.3	Quality of the Raw Water sucking in line	60
5.4.4	Generator Installation above waterline	60
5.4.5	Generator Installation below Water-Line	62
5.4.6	Generator Housing cooled by Raw Water	63
5.4.7	Indirect Cooling of the Genset Housing (by the Heat Exchanger)	64
5.5	The Freshwater Coolant Circuit	64
5.5.1	Position of the external cooling water expansion tank	64
5.5.2	Ventilating at the first filling of the Internal Cooling Water Circuit	65
5.5.3	Pressure Test for Controlling the Cooling Water Circuit	66
5.5.4	Scheme for Freshwater Circuit at Two Circuit Cooling System	67
5.5.5	Pressure Test for Controlling the Cooling Water Circuit	67
5.5.6	Scheme for Freshwater Circuit at Two Circuit Cooling System	68
5.6	Water Cooled Exhaust System	69
5.6.1	Installation of the Standard Exhaust System	69
5.6.2	Installation of the water collector	69
5.6.3	Possible cause: Exhaust duct	70
5.6.4	Possible cause: Coolant duct	70
5.6.5	Installation area of exhaust water collector	70
5.6.5.1	The volume of the exhaust water collector	71
5.6.5.2	Position of the water collector	73
5.6.5.3	Example of the installation of the water collector off-center and possible effects:.....	75
5.6.6	Exhaust / Water separator (optional)	78
5.6.6.1	Installation Exhaust-Water-Separator	78
5.7	Installation of the Fuel System	80



Inhalt / Contents

5.7.1	General References	80
5.7.2	The Electrical Fuel Pump	81
5.7.3	Connection of the Fuel Lines at the Tank	81
5.7.4	Position of the Pre-Filter with Water Separator	82
5.8	Generator DC System Installation	82
5.8.1	Connection to the Starter Battery-Block	82
5.8.2	Connection of the Starter Battery	83
5.8.3	Connection of the remote control panel - see separate control panel manual	84
5.8.4	Installation Panda AGT 12V starter system and internal rectifier unit - sample schema ..	85
5.8.5	Installation Panda AGT 12V starter system and internal rectifier unit - sample schema ..	86
5.8.6	Installation Panda AGT 12V start system and external rectifier unit - sample schema ...	87
5.8.6.1	Electrical fuses - Dipole switch at battery bank.....	89
5.8.7	Generators with external rectifier unit	89
5.8.7.1	Installation of the rectifier unit.....	89
6	Maintenance Instructions.....	91
6.1.1	Checks before starting	91
6.1.2	Hose elements and rubber formed component in the sound cover	91
6.2.1	Checking oil-level	91
6.2.2	Refilling Oil	93
6.2.3	After the oil level check and refilling the oil	93
6.3	Replacement of engine oil and engine oil filter	93
6.3.1	After the oil change	96
6.4	Verifying the starter batterie and (if necessary) the battery bank	96
6.4.1	Battery	96
6.4.1.1	Check battery and cable connections	96
6.4.1.2	Check electrolyt level	96
6.4.1.3	Check electrolyt density	97
6.5.1	Checking the water separator in the fuel supply	97
6.5.2	Ventilating the fuel system	98
6.5.3	Exchange of the Fuel Filter	99
6.5.3.1	Optional fuel filter with sight glass.....	99
6.6	Air circuit maintenance	102
6.6.1	Replace the air filter mat	102
6.6.2	Alternative replacement of the air filter mat with pull out holder	102
6.6.3	Alternative replacement of the air filter at housing with snap fasteners	105
6.7	Coolant circuit maintenance	106
6.7.1	Ventilation of the coolant circuit / freshwater	106
6.8	Replacing the V-belt for the internal cooling water pump	108
6.9	The raw water circuit	109
6.9.1	Clean raw water filter	109
6.10	Reason for frequent impeller wear	110
6.10.1	Replacing the Impeller	110
6.11	Coolant connection block at the generator capsule	112
6.12	Rectifier maintenance	113
6.13	Conservation of the generator (long operation interruption)	115
6.13.1	Measures for preparation of winter storage	115
6.13.2	Initiation during spring	116
7	Generator Failure	117
7.1	Personal requirements	117
7.2	Safety instructions for this chapter	117
7.3	Overloading the generator	118



Inhalt / Contents

7.4	Starting problems	119
7.4.1	VCS does not work	119
7.5	Starting Problems	120
7.5.1	Fuel solenoid valve	120
7.5.2	Stop solenoid	121
7.5.3	Failure Bypass Switch	121
7.6	Troubleshooting Table	122
8	Tables	123
8.1	Table of conduit	123
8.2	Cable cross section	123
8.3	Trouble shooting	124
8.3.1	Generator Voltage too low	124
8.3.2	Generator voltage too high	124
8.3.3	Generator voltage fluctuates	124
8.3.4	Motor does not turn over when starting	124
8.3.5	Motor turns over but does not start	124
8.3.6	Motor does not turn over at normal speed during the start process	125
8.3.7	Motor runs irregularly	125
8.3.8	Motor speed drop down	125
8.3.9	Motor switches itself off	125
8.3.10	Motor stops by itself	126
8.3.11	Sooty black exhaust	126
8.3.12	Generator must be shut off immediatly if	126
8.3.13	Troubleshooting VCS system	126
8.4	Technical Data Engine	127
8.5	Types of Coil	127
8.6	Engine oil	128
8.6.1	Engine oil classification	128
8.6.1.1	Operating range:	128
8.6.1.2	Quality of oil:	128
8.7	Coolant specifications	129
8.7.1	Coolant mixture ratio	129
8.8	Fuel	130
8.8.1	Technical data generator with external rectifier unit	130
8.8.1.1	Technical Data Rectifier unit	130
8.9	Technical data generator with internal rectifier unit	130
8.9.1	Technical data engine	132
9	VCS-AGT-UI	135
9.1	Delivery versions	135
9.2	Voltage control system	135
9.2.1	General working of the VCS	136
9.3	Personal requirements	137
9.3.1	Safety References concerning current	137
9.3.2	Checking of the VCS voltage control when the generator is not running	138
9.3.3	Function of the VCS	138
9.3.4	Checking the VCS voltage regulation	138
9.3.5	Checking the current limiting	139
	Generator Control Panel P6+	141



Inhalt / Contents

Current revision status P6+ manual	142
10 Safety Instructions Generator Control P6+	143
10.1 Personal requirements	143
10.2 Safety instructions for this chapter	143
11 General operation	145
11.1 Panel Generator Control	145
11.2 Rear view 12V-version	146
11.3 Rear view 24V-version	147
11.4 Installation of the remote control panel	148
11.4.1 Placement.	148
11.4.2 Terminal connections	148
11.4.3 Function of the jumpers	149
11.4.4 Configuration and adjustment	151
11.4.4.1 Configuration and setting sheet KE01	151
11.4.4.2 Configuration and setting sheet KE02.....	152
11.4.4.3 Configuration and setting sheet KE03.....	153
11.4.4.4 Configuration and setting sheet KE04.....	154
11.5 Starting preparation / Checks (daily)	155
11.5.1 Marine version	155
11.5.2 Vehicle version	155
11.6 Starting and stopping the generators	156
11.6.1 Starting the generator	156
11.6.2 Stopping the generator	157
11.7 Automatic adapter - optional	158
11.7.1 Function:	158
11.7.2 The mechanism entrance:	158
11.7.3 Terminal connections	160
11.8 Master-Slave adapter - optional	161
11.8.1 Fischer Panda Art. No. 21.02.02.015H 12V-version	161
11.8.2 Fischer Panda Art. No. 21.02.02.01H 24V-version	161
11.8.3 Terminal Connections:	162
11.8.4 Fuse:	162
11.8.5 Terminal connections	162
11.8.5.1 Terminal X2 (IN/OUT from view Master-Operating-Panel).....	162
11.8.5.2 Terminal X3.....	163
11.8.6 Configuration and adjustment	164
11.8.6.1 Configuration and setting sheet KE05.....	164
11.8.6.2 Configuration and setting sheet KE06.....	165
12 Measurements.....	167
12.1 Hole pattern	167



Leere Seite / Intentionally blank



1. Special notes and safety instructions for AGT- Generators

1.1 General safety references concerning operation of an AGT generator.

Special safety precautions must be made with all energy systems, in order to protect the environment of the components against fire.

It is very important to ensure that the main switch on the battery is well accessible, so that in case of danger, this main switch can immediately be separated. However, the main switch must also be mounted close to the battery. If the place is not well accessible, it is necessary to install a power relay instead of the main switch, which can eventually be controlled from different places. The switches for the power relay must be marked as main switch DC battery "switch off at danger".

1.1.1 Cooling of the rectifier block at the marine versions

The rectifier block is cooled with fresh water. A normal cooling of the rectifier block is therefore only possible, as long as the cooling water supply of the generator functions correctly.

Bus bars and radiator boxes are controlled by thermal relays. After a cooling system fault, the diodes must be examined. See chapter failure/maintenance in this manual.

Never start the generator with disconnected battery as the rectifiers can be damaged!

Warning! General Warning



Contact of the electrical contacts may be DANGER TO LIVE!

CAUTION! Danger of electrical impact during contact




1.2 Sample System AGT DC Generator

The AGT-generator is not allowed to be connected to an inverter (without batteries)!


The Inverter generates voltage peaks, which can destroy the rectifiers of the generator!

Attention!: Important Note





A battery must always be connected to the inverter as a capacity!



Recommended capacity

- at 12V \geq 240Ah
- at 24V \geq 120Ah

The screws at the electric rectifier may be pulled tight only with a torque wrench. Recommend torque: see technical datasheet of the diodes (f.e. Torque 6 Nm mechanical and electrical connections of the diode DD171N)

The battery cable must be secured at the generator and at the batteries with appropriate safety devices.

The generator is also include into the CO₂ - fire-extinguishing system.



1.2.1 Measures to the fire protection.

All construction units in the environment of energized parts, which carry more than 50 Amp., must be fire protection-moderately secured.

All junction points at the energized parts must be examined regularly on heating up (infrared thermometers).

In particular temperature differences are a sign of high transition resistances or bad connections of the warmer contact.

1.3 Special Tools

This symbols are used throughout this manual to show which tool must be used at maintenance or installation.



Thermometer



Infrared temperature measuring pistol



Leere Seite / Intentionally blank

2. General References and Regulations

 since 1977	 since 1978	 since 1988	 since 1988	 since 1988
Icemaster GmbH	Fischer Marine Generators	Conclusion Fischer - Icemaster GmbH	100 % water cooled Panda generators	Panda Vehicle Generators

Fischer Panda

FISCHER GENERATORS have been manufactured since 1978 and are a well-known brand for first class diesel generators with especially effective sound-insulation. Fischer has been one of the leading manufacturers for marine generators in respect of quality and know-how during this period. FISCHER, as the worldwide manufacturer of modern marine diesel generators, developed the Sailor-Silent series for example and produced a GFK sound-insulated capsule as early as 1979 and the basis for new generator technology.

The companies Fischer and Icemaster amalgamated under the direction of Icemaster in 1988, in order to concentrate on the development of new products. Production was moved to Paderborn. The amalgamation of the two qualified companies led to the development of a complete new programme within a short space of time. The generators developed at that time set new technological standards worldwide.

The generators became more efficient and powerful than other generators in the same nominal performance range, because of the improved cooling. Panda generator demonstrated its superiority in several tests by renowned institutes and magazines during the past years. The patented VCS (voltage Control System) means it can meet all demands including motor speed. The start-booster (ASB) means Panda generators meet the highest demands in respect of voltage stability and starting values.

A water-cooled Fischer Panda generator, with the same drive motor, produces 15 % more effective output than the majority of conventional generators. This superiority in efficiency also ensures a fuel saving to the same extent.

The Fischer Panda generators are currently manufactured in the performance range from 2 to 200 kW in various versions. Fast running motors are preferred for performances up to approx. 30 kW (nominal speed 3000 resp. 3600 rpm). The heavier slow runners are preferred for the higher range. The fast running generators have proved themselves many times for many uses, that they meet the demands in quality of yachts and vehicles, and offer space and weight saving of 50 % compared to slow running generators.

In addition to the Panda series, Fischer Panda also supply the super compact high-tech sound-insulated battery charging generators from the DC/AC Panda AGT series, which is a very interesting solution for the production of mobile power.

The HTG-alternators ensure that a charging rate of 280 amps is achieved that was scarcely thought possible for this compact construction. This alternator replaces a separate shipboard generators (constant 230 volts AC with up to 3.500 W from the main machine)



2.1 Safety first symbols

These symbols are used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use unit.

This danger symbol refers to toxic danger and draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in severe personal injury or loss of life.

Warning!: Toxic elements



This warning symbol draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in damage or destruction of equipment

Attention!: Important Advice



This warning symbol draws attention to special warnings, instructions or procedures which, if not strictly observed, may result in damage or destruction of equipment

Warning!: Danger of fire



Do not smoke in that area / do not smoke during the describes works

Prohibition!: No Smoking



Fires and open light are ignition sources, which must be avoided.

Prohibition: Fire and open flames prohibited



Do not turn on or start operation. People are working at the generator and/or electrical system

Prohibition: Turn on / start operation prohibited





Berühren der entsprechenden Teile und Anlagen verboten

Proscription!: Do not touch



Generator can be started by an external signal

Warning!: Automatic start.



These symbols refer to electrical danger and points to special warnings, instructions and advices, which must be noticed. Otherwise an electrical shock with personal injury or death can be the consequence.

Warning!: High voltage / danger by electricity - Danger for life



General Warning

Warning!: Danger for life and/or equipment



Substances can be harmful or lead to death, if accumulated or swallowed

Warning!: Harmful if accumulate



Warning of live parts, which can cause electrical impacts during contact. Special danger for persons with heart problems and/or pace makers.

Warning!: Electric shock



Danger of injury by drawing into the machine. Injury by crushes and eventually the separation of extremities. Danger of drawing during contact with extremities, loose clothes, scarf, ties etc.

Warning!: Rotating parts



Warning of materials, which can lead to explosions under certain conditions - e.g. heat or ignition sources

Warning!: Risk of explosion

Surfaces and substances may be hot. Danger of burn / scalding

Warning!: Hot surface

Warning of materials, which cause corrosive damage during contact. These materials can work contaminating when entering into the body.

**Warning!: Danger corrosive material - contermi-
nation of persons possible**

When opening the system the pressure can suddenly escape and drag along liquids. Danger of injury by parts flying around, danger of burn by liquids and gases.

Warning!: System can be under pressure!



Warning!: Hearing damage



Warning!: Magnetic field



Warning!: High pressure




Protective clothing is close fitting, with low resistance to tearing, with narrow sleeves and without protruding parts. It mainly provides protection against being entangled by moving machine parts.

Instruction!: Wear personal protective equipment (PPE)




Wear ear defenders to protect the ears against hearing damage.

Instruction!: Wear personal protective equipment (PPE)




Wear safety glasses to protect the eyes against parts flying around or squirts of fluids. Optical eyeglasses are not replacement for appropriate eye protectors.

Instruction!: Wear personal protective equipment (PPE)



Wearing protective gloves protects the hands against friction, graze, punctures or deep cuts as well as contact with hot surfaces.

Instruction!: Wear personal protective equipment (PPE)



Read and consider the regulations, safety instructions and installation guidelines of manual, in order to avoid dangers and accidents. You protect yourself and the generator.







Instruction!: Read the manual instructions

Environmental protection is the protection of our habitat. For you and your children



Instruction!: Environmental protection

2.2 Tools

This symbols are used throughout this manual to show which tool must be used at maintenance or installation.

	<p>Spanners SW X = required size X mm</p>
	<p>Hook wrench for oil filter</p>
	<p>Screw driver, for slotted head screws and for recessed head screws</p>
	<p>Multimeter, multimeter with capacitor measuring</p>
	<p>Socket wrench set</p>
	<p>Hexagon wrench keys</p>



	Current clamp (DC for synchron generators; AC for asynchron generators)
	Torque wrench



2.3 Manufacturer declaration in accordance with the machine guideline 98/37/EG

Manufacturer declaration in accordance with the machine guideline 98/37/EG

The generator has been developed in such a way, that all assembly groups correspond to the CE guidelines. If machine guideline 98/37/EG is applied, then it is forbidden to start the generator, until it has been ascertained that the system into which the generator is to be integrated, also corresponds to the machine guideline regulation 98/37/EG. This includes the exhaust system, cooling system and electrical installation.

The evaluation of "protection against contact" must be carried out when installed, in conjunction with the respective system. This includes correct electrical connections, a safe ground wire connection, foreign body and humidity protection, protection against humidity due to excessive condensation, as well as overheating through appropriate and inappropriate use in its installed state. The responsibility lies with those who undertake installation of the generator in the final system.

2.4 Customer registration and guarantee

Use the advantages of the customer registration:

- Thus you receive to extended product informations, which are sometimes safety-relevant
- you receive, if necessarily free Upgrades

Far advantages:

By your full information Fischer Panda technicians can give you fast assistance, since 90% of the disturbances result from errors in the periphery.

Problems due to errors in the installation can be recognized in the apron.

2.4.1 Technical Support

Technical Support per Internet: info@fischerpanda.de

2.4.2 Attention, important directions regarding operation!

1. The installation certificate must be completed when taken into use, and certified by a signature.
2. The installation certificate must be despatched within two weeks of use to Fischer Panda.
3. The official guaranty confirmation will be completed by Fischer Panda after receipt and sent to the customer.
4. A guaranty must be shown to make any claims.

Claims against the guaranty will not be accepted of the above said instructions are not, or only partially, carried out.



2.5 Safety instructions - Safety first!

2.5.1 Safe operation

Careful operation is your best assurance against an accident. Read and understand this manual carefully before operating the engine. All operators, no matter how much experience they may have, should read this and other related manuals before operating the generator or any equipment attached to it. It is the owner's obligation to provide all operators with this information and instruct them on safe operation.



2.5.2 Observe safety instructions

Read and understand carefully this manual and „Labels at the engine“ before attempting to start and operate the generator. Learn how to operate and work safely. Know how your equipment and its limitations. Always keep the generator in good condition.

2.5.3 Wear personal protective equipment (PPE)

Do not wear loose, torn or bulky clothing around the machine that may catch on working controls and projections or into fans, pulleys and other moving parts causing personal injury.



Use additional safety items-PPE, e.g. safety protection, safety goggles, gloves, etc.

Do not operate the generator or any equipment attached to it while under the influence of alcohol, medication, or other drugs, or while fatigued.



Do not wear radio or music headphones while operating the generator.



2.5.4 Cleanliness protect

Keep the engine and the surrounding clean.

Ensure that the generator is stopped before cleaning. Keep the generator clean and free of accumulated dirt, grease and trash to avoid fire. Store flammable liquids in proper containers and cabinets away from sparks and heat. Check for leak immediately and repair if necessary.





2.5.5 Safe handling of fuel and lubricants - Keep away from fire

Keep away open fire from fuels and lubricants.

Always stop the generator before refueling and/or lubricating and protect against unintentional starting.

Do not smoke or allow flames or sparks in your work area. Fuel is extremely flammable and explosive under certain conditions.

Refuel at a well ventilated and open place. When fuel and/or lubrication are spilled, refuel after letting the generator cool down.

Do not mix gasoline or alcohol with diesel fuel. The mixture can cause a fire or severe generator damage.

Do not use unapproved containers e.g. buckets, bottles, jars. Use approved fuel storage containers and dispensers.



2.5.6 Exhaust gases and fire prevention

Generator exhaust fumes can be very harmful if allowed to accumulate. Be sure to run the engine in a well ventilated location and where there are no people or livestock near the engine.

Check the Generator and all pipes and hoses regularly for leaks and repair immediately if necessary.

The exhaust gas and the engine can be very hot during operation and afterwards. To prevent a fire, do not expose dry grass, moved grass, or any other combustible material to exhaust gas or the hot generator surface.

To prevent a fire, do not short electrical cables. Check regularly all electrical cables and wires. Uncoated wires and loose connections can cause electrical shock, electrical short circuit and fire.

The generator should be integrated in the local fire protecting system.



CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



Exhaust gases of diesel engines and some components are carcinogenic and can cause deformations and other gene effects.





2.5.7 Cautions against burns and battery explosion

To avoid burns, be cautious of hot components, e.g. muffler, muffler cover, radiator, hoses, engine body, coolants, engine oil, ect. during operation and after the engine has been shut down.



The Coolant system can be under pressure, Open the coolant system only, when the generator is colled down. Wear „Personal Protective Equipment,,.

Be shure that the coolant system is closed and all hose clamps are tightend before operating the generator.



The battery (Starter battery and AGT battery bank) presents an explosive hazard. When the battery is being charged, hydrogen and oxigen gasses are extremly explosive.

Do not use or charge a battery if its fluid level is below the lower mark. Otherwise, the component parts may deteriorate earlier than expected, which may shorten the the service life or cause an explosion. Immediatly, add distilled water until the fluid level is between the lower and the upper marks.



Keep sparks and open flames away from the battery, especially during charging. Do not strike a match near the battery.

Do not check the battery charge by placing a metal object across the terminals (danger of short circuit, battery damage and high danger of explosion). Use a Voltmeter or a hydrometer.



Do not charge a frozen battery. There is a riosk of explosion. When frozen, warm the battery up to at least 16°C.(61°F).

2.5.8 Keep hands away from rotating parts

Operate the generator with closed sound cover capsul only.

Be shure to stop the generator befor checking or adjusting the belt tension.

Keep your hands and body away from rotating parts, such as the cooing fan, V-Belt, fan drive belt, ra´w water pump drive belt, pulley or Flywheel.



Do not operate the generator without safety guards. Install safety guards securly before operation.

2.5.9 Anti-Freeze and disposal of fluids

Anti-freeze contains poison. Wear rubber gloves to avoid personal injury. In case of contact with skin, whash it off immideately. Do not mix different types of Anti-freeze. The mixture can produce chemical reactioncausing harmful substances. Use approved or genuine Fischer Panda Anti-freeze.



Protect the environment. When draining fluids from the generator, place a siutable container underneath the generator body. Consider the relevant enviromental protection regulations when disposing of oil, fuel, coolant, breakfluid, filters and batteries. Do not poor waste onto the ground, down a drain, or into any water source. Conducting safety checks and maintenance





2.5.10 Implementation of security and maintenance

Disconnect the battery from the generator before conducting service. Put a „DO NOT OPERATE“ tag on the remote control panel to avoid accidental starting. Disconnect any automatic starter device, e.g. battery monitor to prevent automatic starting.

To avoid sparks from an accidental short circuit always disconnect the battery’s ground cable (-) first and connect it last. be shure that the generator is stopped and cooleed down when conducting daily and periodic maintaenance, service and cleaning.

Always use the apprppirate tools and fixtures. Verify that they are in good conditions before performing any service work. Make shure you understand how to use them before service.

Keep first aid kit and fire extinguisher handy at all times.



2.6 Warning and caution labels

Keep warning and caution labels clean and free from obstructing material.

Clean warning and caution labels with soap and water, dry with a soft cloth.

Replace damaged or missing warning and caution labels with new labels.

2.6.1 Safety instructions concerning operating the generator

The electrical installations may only be carried out by trained and qualified personnel!

The generator must not be taken into use with the cover removed.

If the generator is being installed without a sound insulation capsule, make sure that all rotating parts (belt-pulley, belts etc) are covered and protected so that there is no danger to life and body!

If a sound insulation covering will be produced at the place of installation, then well-placed signs must show that the generator can only be switched on with a closed capsule.

All servicing-, maintenance or repair work may only carried out, when the motor is not running.

Electrical voltages above 48 volts (battery chargers greater than 36 volts) are always dangerous to life). The rules of the respective regional authority must be adhered to. Only an electrician may carry out installation of the electrical connections for safety reasons.





2.6.1.1 Protective grounding and potential equalisation

In the low voltage board for power supply of the consumers therefore a protective conductor is grounded and connected with electrically conductive objects. The connection with an outer conductor with these object then leads to the earth fault. This earth fault leads to the release of an over-current protection mechanism and thus to the disconnection of the voltage.


2.6.1.2 Ground wire

The generator, is "earthed" as series (centre and ground are connected together in the generator terminal box by a bridge). This is an initial ground fuse, which offers protection, as long as no other measures are installed. Above all, it is conceived for the delivery and possible test run.

This "neutralisation" (Protective Earthing Neutral - PEN) is only effective, if all parts of the electrical system are commonly "earthed" to a common potential. The bridges can be removed, if this is necessary for technical reasons and another protective system has been setup.

There is full current in the AC control box when the generator is running. It must therefore be ensured that the control box is closed and cannot be touched when the generator is running.

The battery must always be disconnected, if work on the generator or electrical system is to be carried out, so that the generator cannot be unintentionally started.



2.6.1.3 Switch off all load when working on the generator

All load must be disconnected, in order to avoid damages to the devices. In addition the semi conductors in the AC control box must be disconnected in order to avoid the boat capacitors being activated. The minus pole of the battery ought to be removed.

Capacitors are required to run the generator. These have two varying functions:

- A) The working capacitors
- B) The (Booster) capacitors

Both Groups are located in a separate AC-Control box.

Capacitors are electrical stores. There could be a residual of high electrical current at the contacts for a period disconnection from the circuit. The contacts may not be touched for safety reasons, If the capacitors are to be exchanged or checked, and then a short circuit between the contacts should be made so that the stored energy is discharged.

If the generator is switched off in the normal manner, the working capacitors are automatically discharged by means of the windings. The booster capacitors are discharged by means of internal discharge resistors.

All capacitors must be short-circuited before work is carried out on the AC-Control box for safety reasons.

Potential equalisation at Panda AGT DC generators.

Further information for your generator see capture installation.





2.6.1.4 Safety instructions concerning the cables

Cable Type

It is recommended is that the cable used be UL 1426 (BC-5W2) compliant, with Type 3 stranding (ABYC Section E-11)

Cable Size

The cable size must be selected taking into account the amperage, voltage and conductor length (from the positive power source connection to the electrical device and back to the negative power source connection.

Cable Installation

It is recommended that a self draining wire loom classified as V-2 or better in accordance with UL 94 be installed in the section of the cable routed in the interior of the sound capsule. Care should be taken to avoid hot surfaces such as the exhaust manifold or engine oil drain bolt and routed clear of any possible sources of chafing.

2.6.2 Recommended starter battery size

Only use batteries which are certified as starter battery by the manufacturer.

Only use batteries with capacity recommended by the engine manufacturer.

Attention !! Check before installation if the starter battery voltage correspond with the generator start system.

f.e. 12V starter battery for 12V start system

f.e. 24V starter battery for 24V start system



2.6.3 Important Advice for Batteries - Starting batteries and Traction batteries

ATTENTION!!! Initial operation:

Installation of battery lines.

Consider the regulations and installation instructions of the battery manufacturer.

Consider ABYC regulation E11 AC and DC electrical systems on boats and/or EN ISO 10133:2000 small watercrafts, electrical systems, low voltage (DC) systems !

Ensure a professional battery installation.

The battery separation can be made mechanically or by an appropriate power relay.

Consider the appropriate notes of the battery manufacturer concerning fire and explosion prevention.

Install a right sized fuse in the positive battery line as close as possible to the battery, but max. 12 inch, 300mm from the battery.

The length of the cable to the fuse, the cable must be protected by a sheath or conduit against damage of the insu-





lation.

Use only cable with self retardant and self extinguishing insulation suitable for high temperatures up to 195F, 90°C.

Install battery lines in a safe way that the cable insulation will not be shaved or damaged.


Battery poles must be protected against short circuits by error.

Inside the capsule of the Fischer Panda Generator the battery positive line must be protected against heat and vibration by a suitable conduit or sheath and must be routed that way it is not touching any area that will get hot under normal operation like entire engine itself, exhaust elbow and exhaust manifold or exhaust lines or the V-belt and pulleys. The cable shall not be too tight otherwise damage will happen.

Run the generator carefully after installation and double check, if there is any possibility for damage of the battery cable. Correct if necessary.



Fig. 2.6-1: Sample scheme for starter battery installation



2.6.4 Safety Instructions for the Handling with Batteries

These instructions must be noticed additionally to the instructions of the battery manufacturer:

- If the batteries are working, someone should be in your near area to help you in a case of emergency.
- Water and soap must be hold ready if battery acid corrode your skin.
- Wear eye protection and protective clothing. During working with the batteries don't touch the eyes.
- If you got a acid splash on your skin or clothing grow it with much water and soap out.
- If you got acid in your eyes rinse them immediately with clear water until no cauterization is noticeable. Visit immediate a doctor.





- Never smoke in the near of the batteries. Avoid naked flames or open fires. In the area of batteries exists danger of explosions.
- Pay attention that no tools fall on the battery poles, if necessary cover them.
- During the installation don't wear a wrist watch or arm jewels, you can create under these circumstances a battery short-circuit. Burning of the skin could be the result.
- Protect every battery contact against unintentional touch.
- For battery banks: Use only cyclical profoundly dischargeable batteries. Starter batteries are not appropriate. Lead-gel batteries are commended. They are maintenance-free, profoundly dischargeable and not produce gas.
- Do not charge a frozen battery.
- Avoid a batterie short-curcuit.
- Take care of a good ventilation of the battery to drain off developing gas.
- The battery connection terminals must be checked of a tight contact at least before operating.
- The battery connection cable must be carefully mounted and checked about incorrect heating at operation with load. The vibrating devices must be regulary checked about scour points and flaw in the isolation.



Attention !! For battery charge generators (Fischer Panda AGT-DC)!

Check before installation if the battery bank voltage correspond with the generator output voltage



Leere Seite / Intentionally blank



3. Basics

3.0.1 Intended use of the machine

The Fischer Panda generator is used to produce electrical energy out of diesel fuel.

The diesel fuel is converted to mechanical energy by the diesel engine. This mechanical energy drives the generator set. In the generator set, the mechanical energy is converted to electrical energy. This process is controlled by the external components, like the remote control panel and the voltage control system (VCS).

For the process a sufficient amount of fuel and combustion air is necessary. Exhaust and heat must be led away.

If electrical power should be applied to a local net, the regulations and installation instructions of the net owner and the regional authorities must be respected. This includes lightning conductor, personal protection switch etc.

Misapplication of the product can damage and destroy the product and the electrical net inclusive all load which is attached to the net, and contain hazards like short circuit. It is not allowed to modify the product in any case. Never open the sound cover during operation. The safety and hazard notes of the manual must be respected.

3.0.2 Purpose of the manual and description of the definitions trained person/operator/user

This manual is work instruction and operation instruction for the owner and user of Fischer Panda generators.

The manual is the base and the guideline for the correct installation and maintenance of Fischer Panda Generators.

The manual does not substitute the technical evaluation and should be used as an example guide only.

The installation must be undertaken and proved by a suitable qualified/trained person and may in accordance with the law as required by the country and special situation.

3.0.2.1 Trained persons

Trained persons for the mechanical components are motor mechanics or persons with similar education and training.

Trained persons for the electrical components are electricians or persons with similar education and training.

After the installation, the trained person must instruct the owner for operation and maintenance of the generator. This must include the hazards of the generator use.

3.0.3 Operator

The operator is the person responsible for the operation of the generator.

After the installation, the operator must be instructed for the operation and maintenance of the generator. This must include the hazards during operation of the generator and an instruction for the maintenance.

The operator must read and follow the manual and must respect the hazard notes and safety instructions.

3.0.3.1 User

Users are persons, established by the operator, to operate the generator.

The operator must assure that the user reads and understands the manual and that all hazard notes and safety instructions are respected. The user must be instructed by the operator regarding his activity at the generator.



3.1 Panda Transport Box

3.1.1 Bolted Fischer Panda Transport Box

1. Remove the bolts for cover / sidewalls
2. Remove the cover
3. Remove the loose accessories
4. Remove the bolts for sidewalls / floor pallet
5. Remove the sidewalls
6. Open the generator attachment

3.1.2 Fischer Panda Transport Box with metal tab closure

1. Bend up the metal tab closures on the transport box lid.
2. Remove the cover
3. Remove the loose
4. Bend open the metal tab closures on the transport box bottom.
5. Remove the sidewalls
6. Open the generator attachment

3.2 Transport and Loading/Unloading

3.2.1 Transporting the generator

- The generator must always be upright for transport.
- For transport, the Fischer Panda Transport Box shall be used for the generator. The generator shall be securely attached to the bottom of the box.
- For loading/unloading, an adequate industrial truck shall be used.
- Depending on the transport distance (e.g. air cargo), the generator fluids (coolant, engine oil, fuel) may have to be drained. The corresponding instructions and warnings must be fitted to the transport packaging.

3.2.2 Loading/unloading of the generator

For loading/unloading the generator, appropriate ring eye bolts shall be installed in the holes in the support rails. The load bearing capacity of each ring eye bolt must at least equal the generator weight.



An adequate lifting yoke shall be used for transport/ loading

Fig. 3.2-1: Lifting yoke (example)



3.3 Scope of delivery

The Fischer Panda PMS generator system contains following components:

3.3.1 PM generator:

Fischer Panda Generator

representative picture

Fig. 3.3-1: Fischer Panda Generator



Remote control panel

representative picture

Fig. 3.3-2: Remote control panel



VCS (Voltage control system) for the voltage control

representative picture

Fig. 3.3-3: AC Control Box



Rectifier unit

Depending on the model, the rectifier unit can be built at the generator or external. If the rectifier unit is an external one, the rectifier unit is apart of the generator and must be in the delivery. It is not allowed to use an independent rectifier unit or a unit from another Fischer Panda generator.


Fischer Panda Manual

The Fischer Panda Manual contains following components:

- Clear foil bag with general informations ect.
- Generator manual with added remote control panel manual
- Spare part catalog „Installation & Service Guide“
- Engine manual from the engine manufacturer.
- Wiring diagram for the generator

representative picture

Fig. 3.3.1-4: Fischer Panda Manual





Optionales components

f.e.:

- Fuel pump
- Installation kit
- Water lock
- ect.

3.4 Opening the MPL sound insulation capsule .

To open the sound insulation capsule, the closures must be rotated roughly 180° counter-clockwise. Use a fl at head screwdriver. Pull the sidewalls out by gripping into the slots.



Closure locked

Fig. 3.4-1: Sound insulation capsule, side part




Fig. 3.4.0-2: Closure locked





Closure open

Fig. 3.4-3: Closure open



3.4.1 Opening the GFK sound insulation capsule

GFK sound insulation capsule with lash closures

Fig. 3.4-1: Lash closures



To open the lash closures pull the handle in arrow direction and lift the lash of the closure pin. After lifting of the lashes, the sound isolation cover upper parts can be removed.

Fig. 3.4-2: Lash closures



3.5 Special maintenance notes and arrangements at long periods of stand still time or shutdown

Stand still is divided into the following groups:



- Short-term standstill (1 to 3 months).
- Medium-term standstill / winter storage (3 to 6 months).
- Long-term standstill (storage) / shutdown (more than 6 months).

3.5.1 Reference note for the starter battery at a long-term standstill

Starter batteries

Notice:

Self-discharge of batteries is a physical and chemical process and cannot even be avoided by disconnecting the battery.



- Disconnect the battery from the generator at a long-term standstill.
- Charge the battery on a regular basis. Follow the notes of the battery manufacturer.

Before charging the battery, check the acid level according to the type of battery and refill each cell with distilled water up to the marking if necessary.

Today's starter batteries are normally maintenance-free.

Deep discharge may damage the battery and may be useless afterwards.

Keep the battery clean and dry. Continuously clean the battery terminals (+ and -) and clamps and lubricate with an acid-free and acid-resistant grease. Make sure there is a good contact of the clamp connections when assembling. If voltage is approx. below 1,95 Volt, the cell should not decline the open-circuit voltage of the battery. This equates approx. 2,1V / cell open-circuit voltage when battery is fully charged.

For a 12 V battery applies 11,7 V lower open-circuit voltage (battery flat) - conservation charging 13,2 V.

For a 24 V battery applies 23,4 V lower open-circuit voltage (battery flat) - conservation charging 26,4 V.

These data relate to a battery temperature of 20-25°C. Consider the specifications of the battery manufacturer.

Fischer Panda recommendation:

Notice:

- Install a battery main switch and turn it to the off-position. (Disrupt the battery circuit)
- Install a sufficient fuse in the positive battery line close to the battery
- Check contacts for corrosion on a regular basis.



3.5.2 Arrangements at a short-term standstill

Short-term standstill (1 to 3 months)

- Measure the charge of battery via the open-circuit voltage
- At stand still >7 days - disconnect the battery (e.g. put battery main switch to 0)
- Within 2-3 months - let the engine run for at least 10 min

3.5.3 Arrangements at a medium-term standstill / winter storage

Medium-term stand still (3 to 6 months)

3.5.3.1 Arrangements for conservation:



- Check the charge of battery and recharge approximately every 3 months if necessary. Consider the specifications of the battery manufacturer.
- Check anti-freeze protection of the cooling water and refill if applicable.
The anti-freeze protection should not be older than 2 years. The content of the anti-freeze protection should be between 40% and 60% to ensure corrosion protection in the cooling water circuit; Refill anti-freeze if necessary.
If cooling water will be drained, for example after a conservation of the engine, no water should remain within the engine during the stand still. At the control unit a correspondent note „NO COOLING WATER“ has to be placed.
- Drain engine oil as required. Refill engine with conservation oil up to maximum at the oil dip stick.
- Drain diesel fuel from tank and refill with conservation mixture (90% diesel and 10% conservation oil - up to max).

Let engine run for 10 min.

- Remove v-belt as required and store packed at a dry place. Protect from UV radiation.

Cover alternator openings.

Attention!

No cleaning fluids or preserving agents may enter the alternator. Danger to destroy the alternator.



- Clean engine according to the manufacturer.
- Inject engine parts and v-belt pulleys with a preserving agent.
- Clean air filter housing and inject with a preserving agent.
- Close suction hole and exhaust opening (e.g. with tape or end caps).
- Drain sea water circuit.
- Close sea cock.
- Clean sea water filter.
- Remove impeller and store.

Carry out a deconservation before recommissioning.

Attention!



3.5.3.2 Arrangements for deconservation after a medium-term standstill (3 to 6 months).

- Check charge of battery and recharge if necessary. Consider the specifications of the battery manufacturer.
- Check anti-freeze protection of the cooling water and refill if applicable.
- Drain engine oil. Renew oil filter and oil according to specification.
- Remove preservation agent of the engine with petroleum.
- Degrease the v-belt pulleys and install v-belt correctly. Check v-belt tension!
- Disconnect turbocharger oilpressure line if existent and refill clean motor oil in pipe.
- Keep engine shut-off lever in 0-position and turn engine several times by hand.
- Clean air filter housing with petroleum, check air filter and renew if necessary.
- Remove covers of the exhaust opening and the suction holes.
- Connect battery. Close battery main switch.
- Install impeller.
- Open sea cock.
- Check sea water filter.



- Keep shut-off lever at generator in 0-position and activate starter for approx. 10 sec. Make a break for 10 sec. and repeat procedure twice.
- Visual inspection of the generator according to initial operation and start generator.

3.5.4 Arrangements at a long-term standstill / shutdown

Standstill (more than 6 months)

3.5.4.1 Arrangements for conservation:

- Check the charge of battery and recharge approximately every 3 months if necessary. Consider the specifications of the battery manufacturer.
- Check anti-freeze protection of the cooling water and refill if applicable.

The anti-freeze protection should not be older than 2 years. The content of the anti-freeze protection should be between 40% and 60% to ensure corrosion protection in the cooling water circuit; Refill anti-freeze if necessary.

If cooling water will be drained, for example after a conservation of the engine, no water should remain within the engine during the stand still. At the control unit a correspondent note „NO COOLING WATER“ has to be placed.

- Drain engine oil as required. Refill engine with conservation oil up to maximum at the oil dip stick.
- Drain diesel fuel from tank and refill with conservation mixture (90% diesel and 10% conservation oil - up to max).

Let engine run for 10 min.

- Remove v-belt as required and store packed at a dry place. Protect from UV radiation
- Disconnect battery. Sprinkle terminals with acid-free grease.

Cover alternator openings.

Attention!

No cleaning fluids or preservative agents may enter the alternator. Danger to destroy the alternator.



- Clean engine according to the manufacturer.
- Inject engine parts and v-belt pulleys with a preserving agent.
- Clean air filter housing and inject with a preserving agent.
- Sprinkle exhaust turbo charger (if existent) with conservation agent at intake and exhaust and close lines again. Sprinkle preserving agent to the intake and exhaust lines than attach again.
- Remove valve cover and sprinkle the inside of the cover, shafts, springs, rocker lever etc. with preserving agent.
- Remove injectors and sprinkle the cylinder area with preserving agent. Keep the shut-off lever on the 0-position and turn the engine by hand for several times. Screw in the injectors with new gaskets. Consider the torsional moments.
- Sprinkle slightly the radiator cap and tank lid and respectively the radiator cap at the expansion tank and reinstall.
- Close intake and exhaust openings (for example with tape or end caps).
- Drain sea water circuit.
- Close sea cock.
- Clean sea water filter.
- Dismount impeller and store.

Carry out a deconservation before recommissioning.

Attention!





3.5.4.2 Arrangements after a long-term standstill (shutdown) / recommissioning (more than 6 months):

- Check the charge of battery and recharge if necessary. Consider the specifications of the battery manufacturer.
- Check anti-freeze protection and level of the cooling water and refill if applicable.
- Drain engine oil. Renew oil filter and oil according specification.
- Remove preservation agent of the engine with petroleum.
- Degrease the v-belt pulleys and install v-belt correctly. Check v-belt tension!
- Disconnect turbocharger oilpressure line if existent and refill clean motor oil in pipe.
- Keep engine shut-off lever in 0-position and turn engine several times by hand.
- Clean air filter housing with petroleum, check air filter and renew if necessary.
- Remove covers of the exhaust opening and the suction holes.
- Connect battery. Close battery main switch.
- Install impeller.
- Open sea cock.
- Check sea water filter.
- Keep shut-off lever at generator in 0-position and activate starter for approx. 10 sec. Make a break for 10 sec. and repeat procedure twice.
- Visual inspection of the generator according to initial operation and start generator.

Fischer Panda recommendation:

After a long-term standstill a complete 150 h inspection according to inspection schedule should be carried out.

Notice:




4. The Panda Generator

4.1 Description of the Generator

4.1.1 Right Side View

Fig. 4.1.1-1: Right Side View




- | | | | |
|-----|-----------------------------------|-----|---|
| 01) | Water-cooled exhaust elbow | 09) | Injection hose raw water |
| 02) | Solenoid switch for starter motor | 10) | Thermo-switch exhaust |
| 03) | Thermostat housing | 11) | Starter motor |
| 04) | DC-alternator 12V | 12) | Cooling water return hose |
| 05) | Oil pressure switch | 13) | Ventilation hose to external cooling water expansion tank |
| 06) | Oil filter | 14) | Generator housing with coil |
| 07) | Sound cover base part | 15) | Air suction housing with air filter |
| 08) | Exhaust output | | |



4.1.2 Left Side View


Fig. 4.1.2-1: Left Side View



- | | | | |
|-----|-------------------------------------|-----|--|
| 01) | Air suction housing with air filter | 10) | Passage for Oil drain hose |
| 02) | Restart protection unit (option) | 11) | Oil dipstick |
| 03) | Electrical fuses | 12) | Fuel filter |
| 04) | Relays | 13) | Raw water pump |
| 05) | Failure bypass switch | 14) | Fuel solenoid valve |
| 06) | Speed sensor spare plug (option) | 15) | Pulley for internal cooling water pump |
| 07) | Sound cover base part | 16) | Ventilation screw thermostat housing |
| 08) | Generator housing with coil | 17) | Stop solenoid |
| 09) | Rectifier under production cover | 18) | Actuator for rpm-regulation |

4.1.3 Front View

Fig. 4.1.3-1: Front View




- | | |
|---|--|
| 01) Ventilation screw internal cooling water pump | 13) Cable remote control panel |
| 02) Stop solenoid | 14) Cable voltage control VCS |
| 03) Pulley for internal cooling water pump | 15) Cable shunt measurement (clamp 9+10) |
| 04) Raw water pump | 16) Cable voltage sense (clamp 7+8) |
| 05) Fuel filter | 17) Starter battery minus (-) |
| 06) Raw water intake | 18) Starter battery plus (+) |
| 07) Connection fuel in | 19) Oil filter |
| 08) Connection fuel out | 20) V-belt |
| 09) Connection external expansion tank | 21) DC-alternator 12V |
| 10) Passage for service battery cable | 22) Clamp device for DC-alternator |
| 11) Passage for service battery cable | 23) Ventilation screw thermost housing |
| 12) Cable fuel pump | |



4.1.4 Back View

Fig. 4.1.4-1: Back View




- 01) Water-cooled exhaust elbow
- 02) Charge controller for DC-alternator
- 03) Generator front cover
- 04) Connection external ventilation valve

- 05) Sound cover base part
- 06) Terminal block for remote control cable with fuses and power relays
- 07) Air suction housing with air filter



4.1.5 View from Above

Fig. 4.1.5-1: View from Above




- | | |
|---|--|
| <ul style="list-style-type: none"> 01) Charge controller for DC-alternator 02) Air suction housing with air filter 03) Thermo-switch cylinder head 04) Injection nozzle 05) Fuel solenoid valve 06) Stop solenoid 07) Ventilation screw internal cooling water pump 08) Raw water intake hose | <ul style="list-style-type: none"> 09) Pulley for internal cooling water pump 10) V-belt 11) DC-alternator 12) Ventilation screw thermostat housing 13) Oil filler neck 14) Valve cover 15) Water-cooled exhaust elbow 16) Ventilation hose to external expansion tank |
|---|--|

4.2 Details of functional units

4.2.1 Control panel

The control panel is fitted with various monitoring functions, which increase functional reliability and operating safety of the generator. Various parts of the generator are monitored with sensors which, when triggered, generate an error message and can shut down generator operation under certain circumstances to prevent damage.

Fig. 4.2.1-1: Control panel



- 01. LED for cooling water temperature red¹
- 02. LED for cooling water level red/yellow¹
- 03. LED for fuel level and air filter replacement red/yellow¹
- 04. LED for AC voltage ok green¹
- 05. LED for winding temperature red¹
- 06. LED for oil pressure red¹
- 07. Battery loading voltage DC charging light
- 08. LED for pre-heat "heat" orange¹

- 09. LED for generator "start" green¹
- 10. LED for generator "stand-by" green¹
- 11. Pushbutton for pre-heat "heat"
- 12. Pushbutton for generator "start"
- 13. Operating hours counter
- 14. Pushbutton panel "off"
- 15. Pushbutton panel "on"

¹ LED green: normal operating mode, LED red: fault, LED yellow: warning, LED orange: active depending on jumper


see remote control panel datasheet for details

Notice!:



4.2.2 The cooling system (Fresh and raw water)


Fig. 4.2.2-1: The coling system (Fresh and raw water)






4.2.3 The fuel and air system

Fig. 4.2.3-1: The fuel and air system



4.2.4 The electrical system

Fig. 4.2.4-1: The electrical system




Connection starter battery

1. Cable for starter battery (-)
2. Cable for starter battery (+)

During the connection to the starter battery it must be always ensured that the contact is perfectly guaranteed.

Fig. 4.2.4-2: Cable for starter battery




Service battery cables

At the front of the sound cover is also the withdrawal for the cable for the service batteries.

1. Passage for service battery (-)-cable
2. Passage for service battery (+)-cable

Fig. 4.2.4-3: Service battery cables




Electrical connections for control

Electrical connections

At the front of the generator also all remaining cables for the electrical connections are depending upon type. The allocation of the connections result from the plan for the AC-Control box. See here:

1. Fuel pump
2. Remote control panel
3. VCS
4. Shunt measurement (clamp 9+10)
5. Voltage sense (clamp 7+8)

Fig. 4.2.4-4: Electrical connections



4.2.5 Sensors and switches for operating surveillance

Thermo-switch at cylinder head

The thermo-switch at the cylinder head serves the monitoring of the generator temperature. All thermo-switches for the generators from Panda 6.000 upward are two-pole and laid out as "openers".

110°C

130°C

Fig. 4.2.5-1: Thermo-switch at cylinder head



Thermo-switch at watercooled exhaust elbow

This thermo-switch is located at the water-cooled exhaust elbow and monitors the temperature of the fresh water circuit. The switch measures at the hottest place, because the flue gases lead from the cylinder head into the exhaust elbow.

120/105°C

Fig. 4.2.5-2: Thermo-switch at exhaust elbow



Thermo-switch at exhaust connection

If the impeller pump drop out and delivers no more raw water, the exhaust connection becomes extremely hot.

98/83°C


Fig. 4.2.5-3: Thermo-switch at exhaust connection



Thermo-switch coil


1. Thermo-switch coil 4x130°C
2. Generator housing
3. Thermo-sensor NTC 981S
(for measuring)

Fig. 4.2.5-4: Thermo-switch coil




Thermo-switch on the (-)- connection bar

Fig. 4.2.5-5: Thermo-switch on the (-)-connection bar




Thermo-switch on the (+)-connection bar

Fig. 4.2.5-6: Thermo-switch on the (+)-connection bar



Thermo-switch on the rectifier block


Fig. 4.2.5-7: Thermo-switch on the rectifier block



Oil pressure switch

In order to be able to monitor the lubricating oil system, an oil pressure switch is built into the system. The oil pressure switch is on the back of the engine (before the electrical starter).

Fig. 4.2.5-8: Oil pressure switch



Failure bypass switch

The failure bypass switch offers the possibility of starting the generator if the electrical control switched off due to an error in the cooling system by overheating.


Fig. 4.2.5-9: Failure bypass switch





4.2.6 The oil circuit

Fig. 4.2.6-1: The oil circuit





4.2.7 External components

Voltage control VCS


The figure shows the control printed board for the VCS voltage regulation. Over this control printed board the control signals are given for the actuator for speed regulation. On the VCS board are also adjustment possibilities for the control parameters.

Fig. 4.2.7-1: VCS



Battery monitor (optional)

Fig. 4.2.7-2: Battery monitor



Remote control panel

Fig. 4.2.7-3: Remote control panel



4.3 Operation Instructions - see remote control panel datasheet



Leere Seite / Intentionally blank



5. Installation Instructions

All connections (hoses, wires etc) and installation instructions are designed and suited for “standard” installation situations.

In situations where Fischer Panda has no detailed information concerning certain installation requirements (such as boot hull specifications, maximum boot speed -and all other conditions concerning special operating situations) the installation instructions should be used as an example guide only.

The installation must be undertaken and proved by a suitable qualified/trained person and may in accordance with the law as required by the country and special situation.

Damages caused by faulty or incorrect installation are not covered by the warranty.

Attention!



5.1 Personal requirements


The described installation must be done by a technical trained person or a Fischer Panda service point.

5.1.1 Hazard notes for the installation

see “Safety instructions - Safety first!” on Page 22.

Follow the general safety instruction at the front of this manual.

Notice!:



Working at a running generator can result in severe personal injury. Therefore before starting work at the generator:

Make shure that the generator ist stopped and the starter battery is diconnected to guarantee that the generator cannot be inadvertently started.

Do not run the generator with removed sound isolation cover.

Warning!: Risk of injury



Improper installation can result in servere personal injuries or material damage.

- Always undertake installation work when the generator is switched off.
- Ensure there is sufficient installation clearance before start working.
- Ensure tidiness and cleanliness at the workplace. Loose components and tools lying around or on top of each other are sources of accidents.
- Only perform installation work using commercially available tools and special tools. incorrect or damaged tools can result injuries.

Warning!: Risk of injury





Oil and fuel vapours can ignite on contact with ignition sources. Therefore:

- No open flames during work on the generator.
- Do not smoke.
- Remove oil and fuel residues from the generator and floor.

Contact with engine oil, antifreeze and fuel can result in damage to health. Therefore:

- Avoid skin contact with engine oil, fuel and antifreeze.
- Remove oil and fuel splashes and antifreeze from the skin immediately.
- Do not inhale oil and fuel vapours.

Danger for Life. Improper handling, operation, installation and maintenance can result in severe personal injury and/or material damage.

Electrical voltages above 48 volts (battery chargers greater than 36 volts) are always dangerous to life. The rules of the respective regional authority must be adhered to. Only an electrician may carry out installation of the electrical connections for safety reasons.

Generator, oil and antifreeze can be hot during/after operation. Risk of severe burns.

During Installation/maintenance personal protective equipment is required to minimize the health hazards.

- Protective clothing
- safety boots
- protective gloves
- Ear defender
- safety glasses

Disconnect all load during the work at the generator to avoid damages at the load.

-Warning!: Danger of fire



Danger!: Danger of poisoning



ATTENTION!: Danger to Life - High voltage



Warning!: Hot surface/material



Instruction!: Personal protective equipment necessary.



Attention!: Disconnect all load



5.2 Placement

Since Panda generators have extremely compact dimensions, they can be installed in tight locations. Attempts are sometimes made to install them in almost inaccessible places. Please consider that even almost maintenance-free machinery must still remain accessible at least at the front (drive belt, water pump) and the service-side (actuator, dipstick). Please also note that in spite of the automatic oil-pressure sensor it is still essential that the oil level has to be checked regularly.



The generator should not be placed in the proximity of light walls or floors, which can have resonance vibrations because of airborne sounds. If this should be unavoidable, then it is recommended that this surface is lined with 1 mm lead foil, which will change the mass and the vibration behaviour.

You should avoid fixing the generator on a slippery surface with little mass (i.e.). This acts as an amplifier of airborne sounds in the most unreasonable case. An improvement can be achieved by reinforcing these surfaces with ribs. In addition, the breakthroughs, which interrupt these surfaces, should be sawed off. The lining of the surrounding walls with a heavy layer (i.e. lead) and foam additionally improve the conditions.

The generator sucks its air from the surrounding engine room. Therefore it must be ensured that sufficient ventilation openings are present, so that the generator cannot overheat.

High temperature of the intake air decline the power of the generator and increases the coolant temperature. Air temperatures of more than 40 °C reduce the power by 2 % per temperature rise of 5 °C. In order to keep these effects as small as possible, the temperature in the engine room should not be higher than 15 °C in relation to the outside temperature.


5.2.1 Advice for optimal sound insulation

The convenient base consists of a stable framework, on which the generator is fastened by means of shock-mounts.

Since the aggregate is "free" downward, the combustion air can be sucked in unhindered.

In addition are void the vibrations, which would arise with a closed soil.

Fig. 5.2.1-1: TGenerator Base



5.3 Generator Connections

Connect all electrical wires within the capsule tightly to the motor and the generator. This is also the case for fuel lines and cooling water lines.

The electrical connections **MUST** be carried out according to the respective valid regulations. This also concerns used cable materials. The cable supplied is meant for laying "protected" (i.e. in pipe) at a temperature up to a max of. 70 °C (160 °F). The on-board circuit must also be fitted with all essential fuses.

Before working (installation) on the System read the **ATTENTION!** section „Safety Instructions“ in this Manual.



5.4 Cooling System Installation - Raw Water

5.4.1 General Information

The genset should have its own raw water (coolant water) inlet and should not be connected to any other engine systems. Ensure that the following installation instructions are complied with:




For the avoidance of galvanic corrosion, refer to the chapter "Service instruction for marine generators (corrosion protection)".

5.4.2 Installation of the thru hull fitting in Yachts

It is good practice for yachts to use a thru hull fitting with an integrated strainer. The thru hull fitting (raw water intake) is often mounted against the sailing direction to induce more water intake for cooling.

For Panda generators, the thru hull inlet should NOT point in the sailing direction! When sailing at higher speeds more water will be forced into the inlet than the pump can handle and your generator will flood!

Fig. 5.4.2-1: Position of the Thru Hull Fitting



5.4.3 Quality of the Raw Water sucking in line

In order to keep the suction resistance in the line at a minimum, the raw water intake system (i.e. sea cock, thru-hull fitting, inlet filter, etc.) must have an inner diameter of at least 1" (25 mm).

This applies also to installation components such as thru-hull fitting, sea cock, raw water filter etc.

The intake suction line should be kept as short as possible. Install the raw water inlet in close proximity to the genset.

After start-up the cooling water quantity must be measured (e.g. by catching at the exhaust). The flow rate, as well as the necessary cross section of the cooling water pipe see section 8.10, "Diameter of conduits," on page 175

5.4.4 Generator Installation above waterline

The Panda is equipped with a direct drive water intake pump mounted directly on the motor. Since the intake pump is an impeller pump there are wearing parts which are likely to require replacement after a period of time. Ensure that the genset is installed so that the intake pump can be easily accessed. If this is not possible, an external intake pump could be installed in an easily accessible location.

If the generator is installed above the waterline, it is possible that the impeller will wear out faster, because after starting, the pump runs dry for some seconds.

The raw water hose should form a loop as near as possible to the raw water inlet of the generator (see picture below). This ensures the pump only sucks in air for a short time. The impeller pump will be lubricated by raw water and the impeller life span will be increased.

By the installation of a check valve in the raw water inlet line, which is under the waterline, this problem can be restricted.

The impeller pump will remain intact longer, if an electrical booster pump is installed, and is strongly recommended in order to preserve the impeller pump.



Never change the impeller for many years, without exchanging the old pump. If the sealing ring is defective within the pump, raw water runs into the sound cover of the genset. A repair is then very expensive.

NOTE:




Replacement impeller and also a spare pump should always be on board. The old pump can be sent back to Fischer Panda.

1. Raw water filter
2. Water cock
3. Thru hull

Make certain that the raw water filter lies above the water level, otherwise with cleaning water can penetrate by the thru hull. An external pre-pump can relieve the impeller.

An external pre-pump can relieve the impeller.

Fig. 5.4.4-1: Generator installation above waterline





5.4.5 Generator Installation below Water-Line

If the generator cannot be attached at least 600 mm above the waterline, a vent valve must be installed at the raw water line.

Possible heeling must be taken into consideration if installed at the "mid-ship line"!

The water hose for the external vent valve is located at the back of the sound insulated cover. This hose is split in the middle and extended respectively at each end by an additional hose and a connecting nipple. Both hose ends must be led outside of the sound cover to one point, if possible 600 mm over the waterline in the mid-ship line. The valve is connected at the highest place to the two hose ends.

The vent valve must be installed directly behind the water pump.

If the water pump ceases, the valve spring ensures that air can enter and therefore, a syphon effect is avoided.

The de-aeration valve must be regularly controlled. If the water pump stops, the valve spring ensures that air enters. It must be opened, cleaned and greased.

Attention:




Fig. 5.4.5-1: Vent Valve



Fig. 5.4.5-2: Connection Vent Valve


Cut the hose for the external vent valve....



...and bend it upwards.


Both hose ends must be led out outside of the sound cover to one point, if possible 600 mm over the waterline at the mid-ships line. The valve is connected at the highest place with the two hose ends.

Fig. 5.4.5-3: Connection Vent Valve



5.4.6 Generator Housing cooled by Raw Water

Fig. 5.4.6-1: Installaton Scheme for Direct Cooling - schema




- 1. Vent valve
- 2. Coolant connection block
- 3. Raw water pump
- 4. Exhaust manifold

- 5. Raw water filter \varnothing 1"
- 6. Water cock \varnothing 1"
- 7. Thru hull



5.4.7 Indirect Cooling of the Genset Housing (by the Heat Exchanger)

Fig. 5.4.7-1: Installation Scheme Indirect Cooling of teh Genset Housing



- | | |
|---|---------------------|
| 1. Vent valve | 5. raw water filter |
| 2. Exhaust manifold | 6. Water cock |
| 3. raw water pump (Raw water impeller pump) | 7. Hull inlet |
| 4. Heat exchanger | |

5.5 The Freshwater Coolant Circuit


5.5.1 Position of the external cooling water expansion tank

Position of the external cooling water expansion tank

The Panda generator is normally supplied with an additional, external cooling water expansion tank. This tank must be installed in such a way that its lower edge is at least 500 mm more highly arranged than the upper edge of the sound cover.

If this 500 mm should be fallen below, i.e. the cooling water expansion tank is lower installed, very large problems can occur with filling and ventilating. Extend and displace the hose lines to the outside or possibly even up to the deck.

Fig. 5.5.1-1: Position of the External Cooling Water Expansion





The external cooling water expansion tank may be filled only up to the lower edge of the lower tension tape (see note "max") in the maximum filling level in cold condition.

ATTENTION!



5.5.2 Ventilating at the first filling of the Internal Cooling Water Circuit

1. Fill up the external cooling water expansion tank with coolant.

Fig. 5.5.2-1: Expansion tank



maximum fill level = „max.“- mark.

The cover of the external expansion tank temporarily must be opened (all other closures are now closed!).

ATTENTION:




2. Open vent screw on the pipe socket of the internal cooling water pump. Close the vent screw when air free water comes out

Check the water level in the expansion tank during the venting. Fill up if necessary.

Never open the vent screw at the water pump while the generator is running

Fig. 5.5.2-2: Venting screw



3. Open vent screw on the thermostat housing. Close the vent screw when air free water comes out

Check the water level in the expansion tank during the venting. Fill up if necessary.

Fig. 5.5.2-3: Venting screw



4. Start the Generator

After filling the generator it must be started. During this first phase of start-up, the generator may not be loaded. Switch the generator off after about 10 sek. of operation!

5. Repeat the steps 1-4 till no air comes out of the vent screw at thermostat housing.

Close the vent screws.

Fill up the expansion tank.

Close the expansion tank.

7. Re-venting process 10 Operating hours after the first start-up (and if necessary)

Also after the first implementing a small amount of air can be reside in the cooling circuit. To ensure an immaculate und actual operating of the cooling system the ventilating process must be repeated casual in the next few days (weeks, if necessary). Small amount of air will still exit out of the ventilating openings, especially if the generator stood still for a long time.

During the ventilating process repeated checks must be made to check the cooling water is indeed circulating. If there are air bubbles in the internal cooling water pump, it could be that the cooling water is not circulating. The generator will heat up very quickly and switch off, because of overheating.

ATTENTION!



Anti-freeze

In the interest of safety, the freezing point of the closed circuit coolant should be checked on a regular basis. Be sure that the coolant/antifreeze mixture is good for at least -15°C (5 °F) and if it is possible that your genset experiences lower temperatures, for example during storage or transportation, then the entire cooling system should be drained and purged

5.5.3 Pressure Test for Controlling the Cooling Water Circuit

Check if a temperature difference exists between cooling water in-flow and cooling water return flow by use of the hand.

Feel the cooling water in-flow line at the internal cooling water pump.


Feel the cooling water return pipe either at the outlet of the water-cooled exhaust elbow union or at the side, where this pipe exits at the heat exchanger.

The temperature difference between in-flow and return should be approx 10 degrees.



5.5.4 Scheme for Freshwater Circuit at Two Circuit Cooling System

Fig. 5.5.4-1: Scheme for Freshwater Circuit at Two Circuit Cooling System



- | | |
|-----------------------|-----------------------------------|
| 1. Expansion Tank | 4. Freshwater pump |
| 2. Exhaust Manifold | 5. Heat Exchanger |
| 3. Thermostat Housing | 6. Cooling Water Connection Block |

5.5.5 Pressure Test for Controlling the Cooling Water Circuit

Check if a temperature difference exists between cooling water in-flow and cooling water return flow by use of the hand.

Feel the cooling water in-flow line at the internal cooling water pump.


Feel the cooling water return pipe either at the outlet of the water-cooled exhaust elbow union or at the side, where this pipe exits at the heat exchanger.

The temperature difference between in-flow and return should be approx 10 degrees.



5.5.6 Scheme for Freshwater Circuit at Two Circuit Cooling System

Fig. 5.5.6-1: Scheme for Freshwater Circuit at Two Circuit Cooling System



- 1. Expansion Tank
- 2. Exhaust Manifold
- 3. Thermostat Housing

- 4. Freshwater pump
- 5. Heat Exchanger
- 6. Cooling Water Connection Block



5.6 Water Cooled Exhaust System


By injecting the outlet raw water into the exhaust manifold, the exhaust gases are cooled and the noise emissions from the exhaust system are reduced.

5.6.1 Installation of the Standard Exhaust System

The generator exhaust system must remain completely independent and separate from the exhaust system of any other unit(s) on board. The exhaust hose has an inner diameter of 30 mm. The water lock must be installed at the lowest point of the exhaust system. An optional noise insulated water lock can also be installed. The exhaust hose descends from the capsule to the water lock. Then the hose rises via the "goose neck" to the silencer (see drawing). The goose neck must be vertical and sit preferably along the ship's keel centre line. In order that the back pressure inside the exhaust is not too high, the total length of the exhaust system should not exceed 6 m (20 ft.).

Exhaust diameter see section 8.10, "Diameter of conduits," on page 175.

Fig. 5.6.1-1: Installation Scheme Standard Exhaust System



- 1. Generator
- 2. Water lock
- 3. Goose neck

- 4. Silencer
- 5. Hull outlet

5.6.2 Installation of the water collector

Unfortunately, it can occasionally occur that, because of an disadvantageous mounting position of the water collector, sea water gets into the diesel engines' combustion chamber. This disables the diesel engine by irreversible damages. Quite frequently, this leads to discussions during which the parties involved in the yachts' construction or the installation of the generator have to explain themselves.

One point in this situation can be clarified definitely:

If sea water gets into the inner section of the engine, this is not possible due to constructional defects of the genera-



tor or to malfunctions on the engine itself. It can only reach the combustion chamber via the exhaust duct and thus get into the engine.

Thereby, the position of the generator and the water collector, as well as the arrangement of the coolant and exhaust ducts plays the decisive role.

If the water collector is arranged in an unfavourable position, the coolant flowing back in the exhaust duct can rise so high, that it reaches the exhaust stack. Since at least one discharge valve is always open when the engine is shut off, the sea water has free access to the combustion chamber. By capillary action, this sea water then flows past the cocks and even reaches the engine oil in that way. (In fact, a surprisingly high oil level is a first indication of an upcoming catastrophe.)

If an usual high oil level can be detected and/or the oil is of a greyish colour, the engine must not be used anymore. This is a certain sign for coolant that got into the oil pan. If the engine is started under these conditions, the water and the oil are mixed into an emulsion. The oil will quickly become so viscous that one will have to call it a paste. In this phase the fine oil ducts are blocked and a few moments later the machine gets destroyed because of insufficient lubrication. Before this happens, an immediate oil change should be made. (Since the water can only reach the engine via the combustion chamber, it can be assumed that the compression rings will start to corrode. These effects have to be discussed with an engine expert. It will certainly be reasonable to immediately inject plenty penetrating oil through the intake stack and to slowly turn the engine with the starter motor.)

The coolant can reach the exhaust area via the exhaust duct as well as via the coolant feed.

5.6.3 Possible cause: Exhaust duct

If the cause is the exhaust duct itself, the following points are to be checked at the duct:

- a) Position of the water collector is too high. The water reaches the exhaust duct.
- b) Position of the water collector is too far away from the middle of the generator. The water reaches the exhaust duct in tilted position.
- c) The water collector is too small relating to the length of the exhaust duct.

5.6.4 Possible cause: Coolant duct

If the generator is not clearly installed 600 mm over the water line, the coolant feed must be equipped with a 'venting valve', which is at least lead out 600 mm over the water line. (This position must also be assured in every tilted position. Therefore the venting valve should be located in the ships' center line, so that it can not move in tilted position.)

- a) Position of the venting valve is too low. The water flows into the exhaust area when the ship is tilted.
- b) Position of the venting valve is too far from the ships' center line. The water reaches the exhaust area when the ship is tilted.
- c) The venting valve does not work, because it jams or it is clogged. (The venting valves' function needs to be checked regularly.)

As it consistently happens that functioning risks are not realised during the laying of the exhaust duct, the following explanations refer explicitly to the exhaust duct. Here, the location, the size and the position of the 'exhaust water collector' play a very decisive part:

5.6.5 Installation area of exhaust water collector

Concerning a water-cooled exhaust system, it must be regarded that - under no circumstances - coolant from the exhaust duct can get into the exhaust elbow area at the engine. If this happens, the coolant can get into the combustion chamber via an open discharge valve. This would lead to irreparable damage at the engine.

In addition to that, one has to reckon with possible tilted positions of sailing yachts, which makes the position of the




water collector even more important. In general one could say that:

The deeper the water collector is located underneath the generator, the better the protection from entering water into the combustion chamber.

The pictures below, the distance between the critical point at the exhaust elbow and the maximum permissible water level in the exhaust duct is stated with 600 mm. This distance should be understood as a minimum distance.

Fig. 5.6.5-1: Installation area of the exhaust water collector




5.6.5.1 The volume of the exhaust water collector

The exhaust water collector must be measured so large, that it can take the entire amount of water flowing back from the exhaust duct. The amount of water depends on the ducts' length (L) and its cross section. While the diesel engine is running, coolant is continuously injected into the exhaust system and is carted outside with the emissions by the exhaust gas pressure. When the engine is turned off, the number of revolutions sinks quite fast. By doing so, the point is reached where the exhaust gas pressure does not suffice anymore to cart the coolant out. All coolant remaining in the duct at that point flows back into the water collector. At the same time, the diesel engine itself continues to cart coolant through the coolant pump, as long as it keeps on rotating.

The water collector must necessarily be measured so large, that it can take the entire amount of coolant and, and the same time, does not exceed the prescribed vertical height of 600 mm up to the critical point at the exhaust elbow.




Fig. 5.6.5.1-1: Volume of the exhaust water collector



If there are any doubts, a verification can easily be made by temporarily using a clear-sighted hose as exhaust hose. In that way, the coolant level can be checked very easily.

Fig. 5.6.5.1-2: Testing the coolant level




5.6.5.2 Position of the water collector

Important Note!

The ideal position of the water collector would be in center underneath the generator. Only in this position it is assured that the water level can not change drastically in tilted position by the water collector moving out of the center line. See the following pictures:

In this picture, the water collector is mounted in center underneath the generator. When the ship tilts, the position of the water collector related to the critical point at the exhaust duct changes only slightly.


Fig. 5.6.5.2-1: Ideal position of the water collector



Tilted position 15 degrees

The distance from the exhaust elbow to the hydrostatic head derated to 540 mm.

Fig. 5.6.5.2-2: Tilted position 15 degrees






Tilted position 30 degrees

The distance of the water level, even in ideal position, changes in a way that only 458 mm distance remain. So the critical distance is under-run already.


Fig. 5.6.5.2-3: Tilted position 30 degrees



Tilted position 45 degrees

In this case the water level rose so high, that the distance constitutes only 325 mm.

Fig. 5.6.5.2-4: Tilted position 45 degrees



Even when the collector is mounted in the ideal spot, at an extremely tilted position of 45 degrees there is still the risk that water can get straight into the discharge stack area through strong rocking motion ('Sloshing'). This shows that the distance of 600 mm represents a minimum size at which, even when installed ideally, the water can slosh into the exhaust elbow when the ship is very tilted or rocks very hard.

Summary:

The preset minimum height of 600 mm must be regarded unconditionally and is only valid, if the water collector is mounted in its ideal position in center underneath the generator. A higher position is highly recommended if it has to be reckoned with tilted positions of 45 degrees.




5.6.5.3 Example of the installation of the water collector off-center and possible effects:

The following pictures are primarily relevant for an installation of the generator with the water collector on sailing yachts. A change in the mounting position caused by tilted position does not have to be reckoned concerning motor yachts. Here it is only necessary to regard that the volume of the water collector is measured so large, that it can take the entire amount of water flowing back and at the same time maintains the minimum distance of 600 mm.

A) Installation of the water collector 500 mm next to the generators center line:


Fig. 5.6.5.3-1: Water collector, 500 mm next to the center line



Tilted position 15 degrees

The distance is only 404 mm instead of the original 600 mm. So this is very close to the critical point.

Fig. 5.6.5.3-2: Tilted position, 15 degrees






Tilted position 30 degrees

The distance between the hydrostatic head and the critical point at the exhaust elbow is only 216 mm. This means that in a tilted position of 30 degrees you already face the highest risk of sea water sloshing into the combustion chamber.


Fig. 5.6.5.3-3: Tilted position 30 degrees



Tilted position 45 degrees


The water level is now at the same height as the critical point at the exhaust elbow. If the ship is sailed in a tilted position of 45 degrees with an installation like this, the infiltration of coolant into the combustion chamber is inevitable. Irreparable damages are preprogrammed.

Fig. 5.6.5.3-4: Tilted position 45 degrees



B) Installation distance between exhaust water collector and generators' center line 1000 mm

Fig. 5.6-5: Exhaust water collector, 1000 mm next to center line






Tilted position 15 degrees

The distance is, contrary to the original 600 mm, only 327 mm. This is very close to the critical point already.


Fig. 5.6.5.3-6: Tilted position 15 degrees



Tilted position 30 degrees

The water level and the critical point at the exhaust elbow are at the same level now. If the ship is sailed in a tilted position of 30 degrees with an installation like that, the infiltration of coolant into the combustion chamber is inevitable. Irreparable damages are preprogrammed.

Fig. 5.6.5.3-7: Tilted position 30 degrees



Summary:

Concerning sailing yachts it must be regarded, that the water collector is mounted in center underneath the generator, at least in reference to the ships' center line. Thus the water collector is prevented from 'leaking' very strongly when the ship is tilted.


The 'leaking' of the water collector leads to a rise of the water level which then gets too close to the exhaust elbows' critical point.



5.6.6 Exhaust / Water separator (optional)


The water flow on the exhaust/water separator unit has an inner diameter (ID) of 30 mm. If the path from the water separator to the raw water outlet is very short, the hose can be further reduced to 1" (25mm) ID.

Fig. 5.6.6-1: In order to reduce the noise level of the generator unit to a minimum, an optional exhaust outlet muffler can be mounted next to the thru-hull fitting. Additionally there is a component at Fischer Panda, which acts as both an "exhaust goose neck", and water separator. With this "exhaust/water separator" the cooling water is derived over a separate pipe. The exhaust noises emanating from the exterior of the yacht are strongly decreased. Particularly the "water splash".



1. Raw water outlet \varnothing 30mm
2. Hose connector \varnothing 30mm
3. Reducer 30/20mm (if required)
4. Hose
5. Hose connector
6. Sea cock
7. Hull outlet
8. Hose Clips

Fig. 5.6.6-2: Water Flow Exhaust Water Separator




5.6.6.1 Installation Exhaust-Water-Separator

If the exhaust/water separator was sufficiently highly installed, a goose neck is no longer necessary. The exhaust/water separator fulfils the same function. If the "Super silent" exhaust system were installed correctly, the generator will not disturb your boat neighbour. The exhaust noise should be nearly inaudible. The best result is reached, if the hose line, which derive the cooling water, is relocate on a short way "falling" directly to the outlet and this outlet is under the waterline.



Fig. 5.6.6.1-1: Installation Exhaust-Water-Separator




- | | |
|----------------------------|----------------|
| 1. Generator | 4. Silencer |
| 2. Silencer / Water lock | 5. Sea cock |
| 3. Exhaust-Water-Separator | 6. Hull outlet |

If the thru-hull exhaust outlet has to be mounted far from the generator, an exhaust-water separator must definitely be installed. The raw water from the separator must then run along the shortest possible path to the thru-hull outlet. For such long exhaust routes, the exhaust hose diameter should also be increased from NW40mm to NW50mm in order to reduce the back-pressure. The exhaust may have a length of over 10m (32 ft.) if the exhaust hose diameter is increased to 50mm. An additional outlet exhaust muffler close to the hull outlet will help further to reduce noise emissions.

The generator will not disturb your boat neighbours, if the "Super silent Exhaust System has been correctly installed. The exhaust noise should be almost inaudible.

Fig. 5.6.6.1-2: Example for an unfavourable Installation



Example of an unfavourable installation:

- Water lock not far enough below the highest level of the generator
- Distance water lock to exhaust/water separator too large



5.7 Installation of the Fuel System

5.7.1 General References


Inside the generator capsule itself, there is the fuel filter installed (exception: Panda 4200 and 4500). Additional fuel filters (with water separator) must be mounted outside the capsule in easily accessible places in the fuel lines between the tank intake fuel pump and the diesel motor's fuel pump.

Generally forward and return fuel flow pipes must be mounted to the diesel tanks. Do not connect the generator fuel supply lines with any other fuel lines of other diesel systems.

- The following items need to be installed:
- Fuel supply pump (12 V - DC)
- Pre-filter with water separator (not part of the delivery)
- Fine particle fuel filter
- Return fuel line to fuel tank (unpressurized)

The fuel supply pump should be mounted as close to the fuel tank as possible. The electric cable for the fuel pump is already installed on the generator (length 5 m).

Fig. 5.7.1-1: Installation Scheme Fuel System





5.7.2 The Electrical Fuel Pump

Electrical Fuel Pump

With the Panda generator is usually supplied an external, electrical fuel pump (12 V DC). The fuel pump must be installed close at the fuel tank. The electrical connections are pre-loaded at the generator with the lead planned.

- Suction height of the pump: max. 1,2 m at 02, bar

Diameter of fuel lines: section 8.10, "Diameter of conduits," on page 175.

Fig. 5.7.2-1: Electrical Fuel Pump



5.7.3 Connection of the Fuel Lines at the Tank

Lead the return fuel pipe connected to the day tank to the floor

The return pipe connected to the tank must be dropped to the same depth as the suction pipe, if the generator is mounted higher than the tank, in order to prevent fuel running back into the tank after the motor has been switched off, which can lead to enormous problems, if the generator is switched off for a long period.

Non-return Valve in the Suction Pipe

A non-return valve must be fitted to the suction pipe, which prevents the fuel flowing back after the generator has been switched off, if it is not possible to use the return flow pipe as a submerge pipe placed in the tank. The instructions "Bleeding Air from the Fuel System" must be read after initial operation or after it has stood still for a long period, in order to preserve the starter battery.

Non-return valve for the Fuel Return Pipe

If the fuel tank should be installed over the level of the generator (e.g. daily tank), then a non-return valve must be installed into the fuel return pipe to guarantee that through the return pipe no fuel is led into the injection pump.

ATTENTION!





5.7.4 Position of the Pre-Filter with Water Separator

Additionally to the standard fine filter a pre-filter with water separator must be installed outside of the sound insulation capsule in the fuel system line (not included in the delivery).

Fig. 5.7.4-1: Pre-Filter with Water Separator



5.8 Generator DC System Installation

Before the electrical system is installed, READ the SAFETY INSTRUCTIONS of this manual FIRST! Be sure that all electrical installations (including all safety systems) comply with all required regulations of the regional authorities. This includes lightning conductor, personal protection switch, fuses etc.

ATTENTION!



5.8.1 Connection to the Starter Battery-Block

It is necessary to install a starter battery for the generator. The generator has its own alternator to charge a starter battery.

It must be ensured that the cable is firstly attached to the generator and finally to the battery. Furthermore, the battery should be fitted as close as possible to the generator, in order to avoid greater voltage deviation. The positive pole is connected to the red lead and the negative pole to the blue lead. The positive wire must be secured with corresponding fuses.

ATTENTION! Consider correct connection sequence



Battery Bank Connection

Wrong connection of the battery bank can cause a short-circuit and fire.

ATTENTION! Right connection of the battery bank .



Install an appropriate fuse and a battery circuit breaker in the plus pole cable of the batterie, but with a distance to the battery of up to 300 mm (12 inch) at maximum.

The cable from the battery to the safety device must be secured with protective pipe/sleeve against chafing through.



For the connection use self-extinguishing and fire-protected cables, which are appropriate for temperatures up to 90 °C, 195 °F.

The batteries must be layed in such a way that they do not chafe through or other mechanical load can be stripped.

The battery poles must be secured against unintentional short-circuit.

The positive battery cable within the generator must be shifted in such a way that it is protected against heat and vibrations by appropriate sleeve/protective pipe. It must be shifted in such a way that it does not affect rotary parts or parts, that become hot in operation, e.g. wheel, exhaust elbow union, tail pipe and the engine. Do not lay the cable too tautly, since otherwise it could be damaged.

Make a test run after the installation and check the laying of the batteries during the test run and afterwards. If necessary, correct the laying.

Examine regularly the cable layings and the electrical connections.

5.8.2 Connection of the Starter Battery

It is necessary to install a starter battery for the generator. The generator has its own alternator to charge a starter battery.


The positive (+) battery cable is connected directly to the solenoid switch of the starter.

Fig. 5.8.2-1: Positive Battery Cable



The negative (-) battery cable is connected to the engine foot.

Fig. 5.8.2-2: Negative Battery Cable




Note! The battery negative pole may not be connected with the boat ground or with the protective grounding of the installation!

The Panda generators 8000 to 30 are equipped with various DC-relays, which can be found under the terminal strip. The various relays have the following tasks (also see the DC circuit diagram)

- Starter motor relay
- Pre-glow relay (glow plugs)
- Fuel pump relay

see wiring diagram


Fig. 5.8.2-3: DC-Relay



Panda generators are equipped with an independent DC starter motor. The connecting lines cross-section from the battery to the DC system should measure 25 mm² or more depending on system.

1. Solenoid switch for starter motor
2. Starter motor

Fig. 5.8.2-4: DC Starter Motor



5.8.3 Connection of the remote control panel - see separate control panel manual

As standard a 12 core connection-cable is included in the supply. Cores are numbered from 1 to 11 and the 12th core is coloured (yellow/green). The control cables are securely connected to the genset. On the back of the control panel there are terminals numbered from 1 - 12. Connect the cores of the control-cable in respective order.


Please ensure that the remote control panel is installed in a protected, dry and easily accessible place.



5.8.4 Installation Panda AGT 12V starter system and internal rectifier unit - sample schema

Sample schema for a standard installation

Fig. 5.8.4-1: 24V DC output, 12V starter system and internal rectifier unit



- | | |
|------------------------------------|-------------------------|
| 1. Generator | 5. Remote control panel |
| 2. Battery block 12V | 6. Voltage control VCS |
| 3. Battery monitor (optional unit) | 7. Starter battery 12V |
| 4. Fuel pump | 8. Fuse |


All electrical safety installations have to be made on board.



5.8.5 Installation Panda AGT 12V starter system and internal rectifier unit - sample schema

Sample schema for a standard installation

Fig. 5.8.5-1: AGT 24V DC output 12V starter system



- 1. Generator
- 2. Battery block 24V
- 3. Battery monitor (optional unit)
- 4. Fuel pump


- 5. Remote control panel
- 6. Voltage control system VCS
- 7. Starterbatterie 12V
- 8. Fuse

All electrical safety installations have to be made on board.

5.8.6 Installation Panda AGT 12V start system and external rectifier unit - sample schema

Sample schema for a standard installation

Fig. 5.8.6-1: AGT 48V DC output 12V starter system and external rectifier



1. Generator
2. Battery block 48V
3. external rectifier unit
4. Fuel pump
5. Remote control panel

6. Voltage control system VCS
7. Starterbatterie 12V
8. Fuse
9. Dipole switch




The AGT-generator is not allowed to be connected to an inverter (without batteries)!


CAUTION!



The Inverter generates voltage peaks, which can destroy the rectifier diodes of the generator!



A battery must always be connected to the inverter as a capacity!



Required cable cross-sections

The following recommended electrical cable dimensions (cross sections) are the minimum required sizes for a safe installation.

Länge/length	1 - 3 m	4 - 6 m	7 - 10 m	11 - 15 m	16 - 20 m
16 mm ²	70 A	63 A	55 A	48 A	42 A
25mm ²	112 A	100 A	88 A	75 A	63 A
35mm ²	155 A	140 A	125 A	110 A	95 A
50mm ²	225 A	200 A	175 A	150 A	125 A
70mm ²	315 A	285 A	250 A	220 A	190 A
95mm ²	425 A	380 A	340 A	300 A	260 A
120mm ²	540 A	490 A	440 A	400 A	360 A

All electrical safety installations have to be made on board.




5.8.6.1 Electrical fuses - Dipole switch at battery bank

It is absolutely essential that the electrical system installation is inspected by a qualified electrical technician. The generator should have its own DC fuse and battery switch in the connection line rectifier unit to battery bank. The fuses should be sized such that the rated current of the generator is not exceeded by more than 25%.

The fuses must be of the slow type.

5.8.7 Generators with external rectifier unit

Fig. 5.8.7-1: External rectifier unit



- | | |
|--|-------------------------------------|
| 1. Electrical fuses and connection thermo-switch heat sink | 4. Thermo-switch (+) rail |
| 2. Main terminal block | 5. Thermo-switch (-) rail |
| 3. Thermo-switch heat sink | 6. Connection storage batteries (+) |
| | 7. Connection storage batteries (-) |

The external rectifier unit must be installed in a fireproof protected area!

ATTENTION!



5.8.7.1 Installation of the rectifier unit

Cooling water connection.

If the generator has no special connection points, the external rectifier unit can be installed in line with the external ventilation valve.

see Fig. 5.4, "Cooling System Installation - Raw Water," on



Page 59

5.9 Voltage Control System - see VCS datasheet

The VCS control is used for the adjustment of the number of revolutions of the engine and thus the voltage of the generator. It belongs to the accessories and is externally attached.



6. Maintenance Instructions

6.1 General maintenance instructions

6.1.1 Checks before starting

- Oil level
- Cooling system leaks
- Visual check for any changes, leaks oil drain system, v-belt, cable connections, hose clips, air filter, fuel lines

Once a month

- Lubrication of actuator-trapezoid thread spindle

For Maintenance Intervalls see „General information for PMS-Generators.“

6.1.2 Hose elements and rubber formed component in the sound cover

Check all hoses and hose connections for good condition. The rubber hoses are very sensitive to environmental influences. They can season fast with dry air, in which environment of muted oil and fuel steams and increased temperature. The hoses must be checked regularly for elasticity. There are operating situations, at which the hoses must be renewed once in the year.

Additionally to usual tasks of maintenance (oil level check, oil filter control etc.) further maintenance activities are to be accomplished for marine aggregates. It belongs control of the sacrificial anode (cooling water connection block) and the front seal cover at the generator.

6.2 Oil circuit maintenance

The first oil change is to be accomplished after a period of operation from 35 to 50 hours. Afterwards the oil is to be changed after 100 hours. For this the oil SAE30 for temperatures over 20°C and SAE20 for temperatures between 5°C and 20°C is to be used. At temperatures under 5 °C oil of the viscosity SAE10W or 10W-30 is prescribed.

Type and amount of required oil see:

See section 8.9, “Technical data generator with internal rectifier unit,” on page 130.

6.2.1 Checking oil-level

You require:

paper towels / cloth for the oil dipstick

The generator must be placed at level.

- with vehicular generators: Place the vehicle on a leveled surface.
- with PSC generators: Place the generator on a leveled surface.
- with marine generators: Measure the oil-level when the ship is not lop-sided.

Run the generator for about 10 minutes to ensure that the engine is warm.

Wait for 3 minutes, so the oil can flow back into the oil pan.

Generator and coolant can be hot during and after operating.

Wear personal protective equipment. (Gloves, protective goggles, protective clothing and safety shoes)

Caution: Burn hazard!



- Assure generator against accidental start.
- Open the generator casing.
- Pull the oil dipstick out of the check rail.
- Clean oil dipstick.
- Put the oil dipstick back into the check rail and wait for 10 seconds.
- Pull the oil dipstick out of the check rail and read off the oil-level at the lower end of the stick.

Oil dipstick

The oil-level is to be checked by means of the oil dipstick. The prescribed filling level must not cross the „Max“-mark.

We recommend an oil-level of 2/3.

Sample picture

Fig. 6.2-1: Oil dipstick - Sample





Fig. 6.2-2: Sample picture Oil dipstick

Oil dipstick EA 300 Engine

The oil-level is to be checked by means of the oil dipstick. The prescribed filling level must not cross the „Max“-mark.

We recommend an oil-level of 2/3.

Sample picture



Oil should be refilled, if the oil-level is under 1/3 between the minimum and the maximum mark.

Fischer Panda recommends an oil-level of 2/3 between the minimum and the maximum mark.

If the oil-level is under the MIN-mark, check how many operating hours went by since the last oil change, by means of your service manual or an existing oil change tag. - with operating hours between 50 and 150 hours it is only necessary to refill oil. See „Refilling oil“ on page 2.

- with 150 operating hours or more the oil should be changed (See your generators' service table)
- if the oil-level is under the minimum mark by less than 50h, there might be a technical problem! In that case, we recommend going to a shop or a Fischer Panda servicepoint.
- if the oil is cloudy or even „creamy“, coolant might have mixed with the oil. See a garage or a Fischer Panda ser-



vicepint immediately.

6.2.2 Refilling Oil

You require:

Engine oil

1. Check oil-level as described under „Checking oil-level“ on page 1.
 2. Oildipstick is pulled out of the check rail.
 3. Open the oil filler cap.
 4. Fill in oil (approx. 1/2 liter) and wait for about 2 min. so this it can flow into the oil pan.
 5. Wipe off the oildipstick and put it into the check rail.
 6. Pull the oildipstick out of the checkrail and check the oil-level. See „Checking oil-level“ on page 1.
- If oil-level is still too low (under 2/3): repeat steps 4-6.

6.2.3 After the oil level check and refilling the oil

- Put the oildipstick back into the check rail.
- Close the oil filling cap.
- Remove potential oil stains and splashes from the generator and surroundings.
- Close the generator casing.
- Remove lock against accidental generator start.

6.3 Replacement of engine oil and engine oil filter

You require:

- Engine oil. See attachment.
- New oil filter (not with generators with EA300 engines)
- Sealings for oil drain screw
- Personal protective gear
- Container to collect used oil (heat resistant and of sufficient size)
- Open-ended wrench for oil drain screw
- Paper towels and cloth
- Oil filter wrench
- Oil resistant mat, so prevent used oil from getting into underground water

The generator must be placed at level.

- with vehicular generators: Place the vehicle on a leveled surface.



- with PSC generators: Place the generator on a leveled surface.
- with marine generators: Change the oil when the ship is not lop-sided.

Run the generator for about 10 minutes to ensure that the engine is warm. Wait for 3 minutes, so the oil can flow back into the oil pan.

Generator and coolant can be hot during and after operating.

Wear personal protective equipment. (Gloves, protective goggles, protective clothing and safety shoes)

Caution: Burn hazard!



1. Prepare generator.

- Assure generator against accidental start.
- Open the generator casing.
- with generators that have an external oil drain hose: Release the oil drain hose from the mounting.
- with generators that have an internal oil drain hose: Open the lead-through for the oil drain hose (left turn of the sealing). Pull out the sealing with the oil drain hose.

Place an oil resistant mat under the oil drain hose area and prepare the container.

2. Loosen oil filling cap

Unscrew the oil filling cap. This is necessary, because otherwise a vacuum will form and the oil can not completely drain off.

Sample picture

Fig. 6.3-1: Oil filling cap



3. Open oil drain screw.

Unscrew the oil drain screw by means of the open-ended wrench from the oil drain hose (rotating direction left). Use a second open-ended wrench to lock. Make sure to do this over the container.

Use spanner size 17mm.



Fig. 6.3-2: Oil drain hose



4. Discharge used oil.

Let the entire amount of oil drain out of the engine. This can take several minutes.




5. Remove used oil filter / clean oil screen

Release the oil filter by turning the filter wrench counter-clockwise. The filter might be full of oil. Make sure to not spill anything and avoid skin contact.

Sample picture



Fig. 6.3-3: Oil filter



Oil screen with generators with EA300 engines

The oil screen should be cleaned every 500 operating hours: to do so follow the instructions in the engine manual.

Use spanner size 17mm.



Sample picture

Fig. 6.3-4: Oil screen



6. Preparing a new filter

Clean the engines' filter holder brush a thin oil layer on the sealing of the new filter.

Fig. 6.3-5: Oil screen sealing ring



7. Mounting the new filter

Carefully screw in the new filter by hand. It must not be tightened too much. Screw in the oil drain screw again and tighten it with the wrench. Use a new sealing for the oil drain screw.

8. Fill in oil (oil fill capacity: see attachment)

Fill the engine oil into the engine via feed hopper. Check oil-level after every 2 liters with the oil dipstick.

9. Check proper filling level. See „Checking oil-level“ on page 1.

When the proper filling level is reached, screw in the oil cap again. Run the engine for 10 minutes and then turn it off. Check the oil-level once more after several minutes with the oil dipstick. If it is too low, refill some oil.

10. Clean up



Wipe off all oil splashes from the generator and make sure that the drain screw has no leak.

6.3.1 After the oil change

- Put the oil dipstick back into the check rail.
- Close the oil filling cap.
- Remove potential oil stains and splashes from the generator and surroundings.
- Close the generator casing.
- Remove lock against accidental generator start.

11. Duly disposal of used oil and filter

Used oil is very toxic and must not be disposed with domestic waste. It is prohibited to dispose used oil with waste water! Make sure that used oil is disposed properly (e.g.: where oil is bought or at collection stations).

6.4 Verifying the starter batterie and (if necessary) the battery bank

Check the condition of the battery. Proceed here as prescribed by the battery manufacturer.


If from the battery manufacturer not otherwise mentioned

6.4.1 Battery

6.4.1.1 Check battery and cable connections

- Keep battery clean and dry.
- Remove dirty clamps.
- Clean terminal posts (+ and -) and clamps of the battery, and grease with acid-free and acid-resistant grease.
- When reassembling, ensure that clamps make good contact. Tighten clamp bolts hand-tight.

Fig. 6.4.1-1: Battery




6.4.1.2 Check electrolyt level



- Remove sealing caps 1.
- If testers 2 are present:
- Electrolyte level should reach the base of these.
- Without testers:
The electrolyte level should be 10-15 mm above the top of the plates.
- If necessary, top up with distilled water.
- Screw sealing caps back in.


Fig. 6.4.1-1: Battery



6.4.1.3 Check electrolyt density

- Measure the electrolyte density of individual cells with a commercial hydrometer. The hydrometer reading (see table on following page) indicates the battery's state of charge. During measurement, the temperature of the electrolyte should preferably be 20 °C.

Fig. 6.4.1-1: Battery



Electrolyte density		
in [kg/ l]		Charge status
Normal	Tropical	
1.28	1.23	well charged
1.20	1.12	semi-charged, re-charge
1.12	1.08	discharged, immediately charge

The gases emitted by the battery are explosive! Keep sparks and naked flames away from the battery!

Attention

Do not allow battery acid to come into contact with skin or clothing!

Wear protective goggles!

Do not rest tools on the battery!



6.5 Fuel circuit maintenance

6.5.1 Checking the water separator in the fuel supply

The pre-filter with water separator has a cock at its lower surface, with this cock the downward sunk water can be discharged.

Fig. 6.5-1: Fuel filter with water separator




6.5.2 Ventilating the fuel system

Normally, the fuel system is designed to ventilate air itself i.e. as soon as the electric starter motor starts operation the fuel pump starts working and the fuel system will be de-aerated after some time automatically. It is nevertheless essential to ventilate the system as follows prior to the first operation (as all hoses are empty):

1. Main power switch "OFF"
2. Press failure bypass switch and keep firmly pressed.
The electrical fuel pump must be audible. Switching on and off the solenoid valve at the generator will be audible by pressing the failure bypass switch (if capsule removed).

Fig. 6.5.2-1: Failure bypass switch




3. Pressing the failure bypass switch for approx 3 - 4 minutes will loosen the ventilation screw located at the fuel solenoid valve. The button must continue to be pressed, whilst opening the screw. A large cloth or Kleenex tissue must be laid beneath the connection to prevent escaping fuel running into the capsule. If the fuel runs out without air bubbles, then the ventilation screw can be closed. Only then may the button be released.

Use spanner size 10mm.



Fig. 6.5.2-2: Ventilation screw at the fuel solenoid valve





Not all generator models has a fuel solenoid valve. At generators without fuel solenoid valve, a single ventilation screw is installed.

Note!:




Fig. 6.5.2-3: Injection nozzles

4. Pressing the starter button can now start the machine. The machine should start after a short period.
5. If this does not occur, then a connecting nut fitted to the injection line must be loosened and starting procedure repeated. Retighten the washers after successfully starting. The injection line must be raised by several millimetres.

Use spanner size 17mm.



6. Switch main switch "OFF"



6.5.3 Exchange of the Fuel Filter

Exchanging the filter, depending upon fuel contamination, should take place after 300 operational hours at the very least. T

he inlet must be clamped, before exchanging the filter.

Remove the hoses from the used filter and fasten them to the new filter. The arrow on the filter housing indicates the direction of the fuel flow. A clogged filter causes a decreased power output of the generator.

Fig. 6.5.3-1: Fuel Filter




6.5.3.1 Optional fuel filter with sight glass

The filter change depends on the fuels' degree of pollution, but should be executed every 300 operating hours at the latest.

01. Fuel filter housing
02. Fuel filter element
03. Sight glass

Fig. 6.5.3-1: Fuel filter



Unscrew the housing from its mount (left hand rotation).

Fig. 6.5.3-2: Fuel filter



Unscrew the filter element from the mount (left hand rotation).

Fig. 6.5.3-3: Fuel filter





Screw the new filter element into the mount.

Lubricate the sight glasses o-ring with a heat resistant grease (Specification: Antiseize) and screw the sight glass back into its mount (right hand rotation).

Fig. 6.5.3-4: Fuel filter



6.6 Air circuit maintenance


6.6.1 Replace the air filter mat

1. Open the air suction housing by loosen the six screws on the housing cover.

Use spanner size 8mm.



Fig. 6.6-1: Air suction housing



2. Change the air filter mat
3. Close the suction air housing

Fig. 6.6-2: Opened air suction housing



6.6.2 Alternative replacement of the air filter mat with pull out holder



1. Air filter housing with pull out holder

Fig. 6.6.2-1: Air suction housing with pull out holder




2. Tip the two fasteners 90°

Fig. 6.6.2-2: Air suction housing with pull out holder




3. Pull the filter mat holder out

Fig. 6.6.2-3: Air suction housing with pull out holder



4. Replace the air filter mat
5. Assembly in reversed order

Fig. 6.6.2-4: Air Suction Housing with pull out holder






6.6.3 Alternative replacement of the air filter at housing with snap fasteners

1. Open the combustion air housing by loosening the closure on the right side of the housing.

01. Closure


Fig. 6.6.3-1: Air suction housing



2. Open the combustion air housing by loosening the closure on the left side of the housing.

01. Closure

Fig. 6.6.3-2: Air suction housing




3. Open the air housing by pulling the cover.
4. Lift out the air filter element of the cover of the air filter housing.

01. Air filter

5. Replace cover in reverse procedure.

Sample picture

Fig. 6.6.3-3: Air Suction Housing



6.7 Coolant circuit maintenance

6.7.1 Ventilation of the coolant circuit / freshwater

Special notes for the ventilation of the cooling system

If the cooling water is drained, or if other air has entered the cooling system, it is necessary to ventilate the cooling system. This ventilating procedure must be repeated several times:

The generator must be switched off before opening the ventilating points!

Pay attention that the external coolant expansion tank is connected with the generator by the intended connection point.

Further it should be guaranteed that the expansion tank is attached in sufficient height (600 mm) over the level of the generator exhaust elbow union.

Expansion tank

Attention



Fig. 6.7-1: Expansion tank




1. Open the ventilating screw above the cooling water pump casing.

Use spanner size 10mm.



Fig. 6.7-2: Ventilating screw






2. Open the ventilating screw on the thermostat casing.
Use spanner size 10mm.



Fig. 6.7-3: Ventilating screw on the thermostat housing



3. Pour cooling water into the cooling water filling necks.
(At generators without filler, The cooling water can be filled into the external expansion tank instead)
4. If the cooling water level no longer drops (the cooling water level in cold waters must cover the tin in the exhaust elbow), close the filler cover and the cooling water screws and then start the generator.
5. Run the generator for approx. 60 Seconds, then switch off
6. Refill cooling water via the compensation tank.
7. The compensation tank is connected to the generator by two hoses.

Fig. 6.7-4: Cooling water filler cap




The external compensation tank should be filled to a max 20% in a cold state. It is very important that a larger expansion area is maintained above the cooling water level.

8. Repeat this procedure 1 - 5 times.

If there is no change to the state of the cooling water level, the generator is re-started for 5 minutes. Thereafter the de-aeration must be repeated two to three times.

The ventilation screw above the cooling water pump casing may not be opened under any circumstances, whilst the generator is running. Air will be sucked through the opening, if this should happen by mistake. Venting the whole system afterwards is necessary and very difficult.

Fig. 6.7-5: Ventilation screw above the cooling water pump casing



6.8 Replacing the V-belt for the internal cooling water pump


The relative high ambient temperature in the closed sound insulated capsule (about 85°C) can be a reason for a reduced lifespan of the v-belts. It is possible that the "softener" in the rubber compound lose their effect after a short operating time because the air in the sound insulated capsule can be relative warm and dry. The v-belt must be controlled at very short time intervals. It may be required to change the v-belt after several weeks because of unfavourable conditions. Therefore, control should be carried out after an interval of 150 operating hours. The v-belt is a wearing part. There should be enough spare v-belts on board. We recommend that you have the respective manual within reach.

1. Loosen the screw on the deflection pulley bracket.

Use spanner size 13mm.



Fig. 6.8-1: Screw on the deflection pulley bracket




2. Loosen the screw beneath the alternator.

Use spanner size 13mm.




Fig. 6.8-2: Screw beneath the alternator





3. Press the alternator in the direction of the thermostat casing
4. Exchange Belt Pulleys

Fig. 6.8-3: DC alternator




5. Re-tighten Belt Pulleys

The belt pulleys should only be tightened to the extent that it can be pushed to the length of a thumb (approx. 10 mm).

6. Re-tighten the screws above and below the alternator

Fig. 6.8-4: Drawing belt pulley



6.9 The raw water circuit

6.9.1 Clean raw water filter

Residue should be regularly removed from the seawater filter. The seacock must, in each case, be closed first. It often suffices to merely hit the filter punnet.

If water should seep through the cover of the seawater filter, this may never be sealed with adhesive or sealant. The cause for the leakage must be sought. The sealing ring between caps and filter holders must be exchanged in the simplest cases.

Fig. 6.9.1-1: Raw water filter



6.10 Reason for frequent impeller wear

1. Unreasonable operating conditions

The Cooling water pump Impeller must be regarded as a wearing part. The life expectancy of an impeller can vary greatly and depends exclusively upon the operating conditions. The PANDA Generator cooling pumps are so designed that the speed of the pump in comparison to other generators is relatively low. This has a positive effect on the life expectancy of the pump.

2. Longer Suction Distance of Cooling Water

If the cooling water suction distance is long, or is blocked, this has a negative effect on the impeller, so that an under-pressure occurs in the cooling water suction area. This can reduce the efficiency of the impeller and place strain on the blades. This can greatly reduce the life expectancy.

3. Operating in contaminated waters

The impeller is placed under great strain in waters with high contamination. The use of the impeller in coral waters is also critical. There are known cases, whereby the impeller was so fatigued after 100 hours use, that the lip seals were grinded away by the shaft. In these cases sharp crystal parts from the coral press into the rubber seals and act as a grinding material on the stainless steel shaft of the impeller pump.

4. Generator mounted above the water level


It is especially disadvantageous for the impeller pump, if the generator is mounted above the water level. This means that a few seconds will pass before the impeller can suck in cooling water. This short dry running period damages the impeller. The increased wear can also lead to a breakdown. (See special instruction: "Effect on the impeller pump, if the generator is mounted above the water line").

6.10.1 Replacing the Impeller

Raw water valve

1. Close the raw water valve.

Fig. 6.10.1-1: Raw water valve






Raw water pump

The raw water pump is located on the front side of the genset.

Fig. 6.10.1-2: Raw water pump




Cover raw water pump

2. Remove the cover of the seawater pump by loosen the 4 wing screws from the housing.



Fig. 6.10.1-3: Cover raw water pump



Impeller

3. Remove the impeller from the shaft by means of multi grip pliers..
4. Mark the impeller, to make sure that it is in the correct position when re-installation is carried out.





Fig. 6.10.1-4: Impeller



5. Check the impeller for damage and replace it if necessary.
6. The impeller should have been lubricated with glycerine or with a non-mineral oil based lubricated e.g. silicone spray, before re-insertion into the housing. Attention: This is very important, because the impeller can quickly be damaged.

Cover Pump Shaft

7. Attach the impeller to the pump shaft (if the old impeller is re-used, initially check the marking).
8. Fastening the cover and use a new seal.



Fig. 6.10.1-5: Impeller



Fig. 6.10.1-6: Cover pump shaft




6.11 Coolant connection block at the generator capsule

Control of the coolant connection block

The coolant terminal block at the side of the generator housing must be thoroughly checked in the case of all seawater-cooled generators.

Fig. 6.11-1: Coolant connection block






6.12 Rectifier maintenance

Furthermore in addition to the standards checks according to the manual following points of the generator have to be checked:

- Automatic shut down of the generator in case off high heating temperature

This shall be done by disconnecting the thermo-switch of the heat sink. Next to the rectifier you will find a 2-pole connector. If you disconnect this connector from the opposite socket, the generator shall shut down – or, when the generator is not running you will get a signal on the panel.


Fig. 6.12-1: Plug thermo-switch cooling plate



Temperatures of the rectifier and heating

- Apply a thermocouple meter to the heat sink and the copper bars and monitor the maximum temperatures of the rectifier.

Fig. 6.12-2: Measuring the temperature



- With the help of the infrared thermometer you can check all the temperatures on the rectifier.


Check all the cable connections of the DC- wiring.

The temperature of the heat sink shall never exceed 95°C.

The temperature of the copper bars shall never exceed 120°C




Fig. 6.12-3: Measuring the temperature



Ensure, that a fuse next to the battery is installed in the battery line for the generator output cable.

Ensure that a battery switch is installed in the battery line. Never leave the generator behind without the cover mounted over the heat sink and capsule not closed.

Fig. 6.12-4: Connection example



Remind the customer

- to run the generator only with closed capsule.
- not to run the generator unattended
- to ask for regular service



6.13 Conservation of the generator (long operation interruption)

6.13.1 Measures for preparation of winter storage

1. Rinse seawater circuit with an anti-freeze solution, if this contains a corrosion protection solution. The seawater intake must be stopped at the seacock. The anti-freeze protection mixture is to be sucked up from a container by means of a hose connection. The cooling water mixed with the exhaust gases should be fed back to the suction container. The circuit must be kept upright some minutes to ensure the anti-freeze protection mixture reaches all parts of the cooling system.
2. The anti-freeze mixture concentration in the internal cooling circuit must be checked with a suitable measuring instrument. The concentration must be adequate for the lowest expected temperatures.
3. Clean seawater filter and check seal.
4. Check seacock for practicability. And spray with a corrosion protection oil from the inside or lubricate with acid-resistant grease.
5. Check all hoses and hose connectors for good condition. The rubber hoses are very sensitive to environmental influences. They can deteriorate quickly in environments with dry air, light oil, fuel fumes and increased temperatures. The hoses must be checked regularly for elasticity. The hoses must be renewed once in the year in particular operating situations.
6. Doubly check the hose connections at all seawater valves, and if possible protect them with double hose clamps.
7. Dismount the cooling water pump impeller and check for wear. The impeller may not remain in the pump. It must be greased with Vaseline and be kept in a dark place. It can be re-integrated again into the pump, during the spring, if it is in good condition. The impeller is a wearing part, and it is recommended that it is always renewed in the spring, depending upon the number of hours the generator has been running.
8. Control of the vent valve at the seawater inlet. A vent valve is always necessary, if the generator is installed below the waterline. The vent valve must also be regularly checked during the season. The vent valve should always be disassembled, checked and greased during winter storage. Hardened or dirty parts are to be replaced.
9. Check water lock: If the generator were rinsed with an anti-freeze mixture, the anti-freeze mixture can escape from the water lock. If the generator were rinsed with fresh water, the water in the water lock must be drained. Otherwise there is a danger of the collector being destroyed by ice through expansion.
10. Check the exhaust/water separator for leakage and whether the hose connections at the lower surface of the separation unit are in normal condition. (in the case of extremely sulphurous fuels, it is possible that high-grade steel tube ends are attacked.)
11. Check all construction units of the generator inside the sound cover for leakages. If there are traces of humidity in the sound cover, the cover must be dried. Furthermore, the cause for damp must be searched and eliminated.
12. During the winter storage the upper section of the sound insulated capsule must be taken off, in order to avoid condensed moisture formation, if traces of humidity remain in the sound insulation capsule inside casing by leakages in the seawater circuit.
13. The generator housing and the housing of the engine should be sprayed with a corrosion protection oil before the winter storage. This procedure is recommended also in the season. This procedure can avoid that arising and humidity marks on the surface of the aluminum construction units be noticed too late.
14. Disconnect the starter battery (positive and negative pole).
15. Lubricate the spindle for the number of revolutions adjustment device with a special lubricant (Antiseize grease).
16. Check cooling water connection block at the generator housing on traces of corrosion and if necessary renew. (Only such traces are to be considered, which refer to clear "blossoming" of the material. If the surface is only grey coated, this is only an indication for the fact that aluminum came into contact with condensed moisture.)
17. Use of a air dehumidifier. The best way to protect a yacht in the winter storage against damage by humidity is, to place a air dehumidifier inside the ship and lock all hatches. The devices have a hygrometer, which switches the device off, if the humidity is under the adjusted value. There is no better method, in order to protect pads, cable, electronics, wood, engines etc. optimally against any rotting by humidity.



6.13.2 Initiation during spring

- Before starting, turn the engine once with the hand, in order to eliminate the beginnings of existing corrosion to the bushes. If necessarily carry out normal engine inspection.
- Change engine oil and engine oil filters.
- Reintegrate the impeller of the cooling water pump and check pump for leakage.
- Charge starter battery of the generator, connect cables and check battery voltage.
- Start generator and check the basic adjustments of the generator such as voltage, speed regulation etc...
- Check all switching off devices for function by operational procedures.



7. Generator Failure

7.1 Personal requirements

The work described here, unless otherwise indicated, are performed by the operator.

More repair work may be performed only by specially trained personnel or by authorized repair shops (Fischer Panda service points). This is especially for working on the valve timing, fuel injection system and the engine repair.

7.2 Safety instructions for this chapter

see "Safety instructions - Safety first!" on Page 22.

Follow the general safety instruction at the front of this manual.

Danger for life! - The generator can be equipped with an automatic start device. This means the generator can be started by an external signal. To avoid an unexpected starting of the generator, the starter battery must be disconnected before starting work at the generator.

Working at a running generator can result in severe personal injury. Therefore before starting work at the generator:

Make sure that the generator is stopped and the starter battery is disconnected to guarantee that the generator cannot be inadvertently started.

Do not run the generator with removed sound isolation cover.

Improper installation/maintenance can result in severe personal injuries or material damage.

- Always undertake installation/maintenance work when the generator is switched off.

- Ensure there is sufficient installation clearance before starting work.

- Ensure tidiness and cleanliness at the workplace. Loose components and tools lying around or on top of each other are sources of accidents.

- Only perform installation work using commercially available tools and special tools. Incorrect or damaged tools can result in injuries.


Oil and fuel vapours can ignite on contact with ignition sources. Therefore:

- No open flames during work on the generator.

- Do not smoke.

- Remove oil and fuel residues from the generator and floor.

Notice!



Warning!: Automatic start



Warning!: Risk of injury



Warning!: Risk of injury



Warning!: Danger of fire



Contact with engine oil, antifreeze and fuel can result in damage to health. Therefor:

- Avoid skin contact with engine oil, fuel and antifreeze.
- Remove oil and fuel splashes and antifreeze from the skin immediatly.
- Do not inhale oil and fuel vapours.

Danger for Life. Improper handling, operation, installation and maintenance can result in severe persoanl injury and/or material damage.

Electrical voltages above 48 volts (battery chargers greater than 36 volts) are always dangerous to life). The rules of the respective regional authority must be adhered to. Only an electrician may carry out installation of the electrical connections for safety reasons.

Generator, oil and antifreeze can be hot during/after operation. Risk of severe burns.

During Installation/mainenance personal protective equipment is required to minimize the helth hazards.

- Protective clothing
- safety boots
- protective gloves
- Ear defender
- safety glasses

Disconnet all load during the work atthe generator to avoid damages at the load.

Danger!: Danger of poisoning



ATTENTION!: Danger to Life - High voltage



Warning!: Hot surface/material



Instruction!/: Personal protective equipment necessary.



Attention!/: Disconnect all load



7.3 Overloading the generator

Please you make sure that the engine is not overloaded. An overloading in the long term can harm the engine. In addition the exhaust gases are soot-blackened (environment).

The full rated output of the generator is primarily intended for brief use.

As fatigue strength should be calculated in the interest of a long life span of the engine 70% of the nominal load.

Warning!/:



7.4 Starting problems


7.4.1 VCS does not work

For start problems one chief cause is that the VCS does not work. Check:

Is the voltage sense connection ok? Check polarity!

Terminal 7+8


Fig. 7.4.1-1: Terminal 7+8



Is the shunt connection ok? Check polarity!

Terminal 9+10

Fig. 7.4.1-2: Terminal 9+10



Is the main supply connection ok? Check polarity!


Does DP+ (VCS ON) lie on clamp 6 of the plug with 6 pins?

Fig. 7.4.1-3: Terminal 1-6



Checking the fuse on the VCS printed circuit board.

Fig. 7.4.1-4: Fuse on VCS circuit board



7.5 Starting Problems

7.5.1 Fuel solenoid valve

For start problems the possibility of an error exists with the solenoid for engine stop or fuel solenoid valve, which both effect affect simultaneous on the fuel system.

The fuel solenoid valve is located in front of the injection pump. It opens automatically, if the "START"-button is pressed on the remote control panel. The solenoid valve is CLOSED when the generator main power is switched "OFF". For this reason, it requires a few seconds before the motor comes to a full halt.


If the generator fails to start, runs rough, does not reach the proper RPM, or does not stop properly, the first item to suspect in most cases is the fuel solenoid valve and should be inspected first.

A check of the fuel solenoid valve by removing the plug from the fuel solenoid valve for a short period whilst in operation (first remove the small retention screw) and replace it immediately. The motor should "react immediately" by revving high. If the motor does not react sharply to the reconnection of the solenoid wire, it is a sign that the solenoid

Fuel solenoid valve

01. Fuel solenoid valve
02. Fuel injector nozzles
03. Ventilation screw

Fig. 7.5.1-1: Fuel solenoid valve





7.5.2 Stop solenoid

Stop solenoid for engine stop

Fig. 7.5.2-1: Stop solenoid




7.5.3 Failure Bypass Switch

The start-failure bypass switch enables an immediate restart facility of the generator, should it cut out, even if this was caused by over-heating. There is normally a requirement to wait until the motor has cooled down to the correct temperature. This can last for several hours in certain circumstances, since the generator is enclosed in a sound-insulated casing, which prevents heat loss.

Failure bypass switch

Fig. 7.5.3-1: Failure bypass switch



This period can be reduced by pushing the button on the front of the generator. The generator can be started by means of the remote control as long as the button is depressed. The switch/button bypasses any faults allowing the generator to run.

Before depressing the button, a manual check of the oil dip stick must be carried out to determine whether the generator has sufficient oil, as it is possible that the oil pressure switch causes the generator to cut out. If it has been ascertained that the reason for the motor cutting out is overheating and not lack of oil, the generator can be run for several minutes without load, so that the motor is cooled by the circulating coolant.

If the temperature is the reason for the generator cutting out when it is running under load, then an immediate check must be made to determine the cause. It could be a fault with the cooling system, one of the fans, the air-intake or a fault with the external cooling system.

Note:

Continual use of the starter-failure bypass switch should be avoided, while the generator cuts out during operation.

The generator must always run without load for several minutes before being switched off, so that a temperature compensation occurs. Heat accumulation can cause the generator to overheat, even after it has been switched off.

Should the overheating alarm be set off, caused by heat accumulation, after the generator has been switched off, then this can also be bypassed using the switch.

7.6 Troubleshooting Table

For Troubleshooting see Table 7.6, "Troubleshooting Table," on Page 122



8. Tables

8.1 Table of conduit

Fig. 8.1-1: Table of conduit

Generatortype	Ø Cooling water conduit		Ø Exhaust conduit [mm]	Ø Fuel conduit	
	Fresh water [mm]	Seawater [mm]		Supply [mm]	Return [mm]
Panda PMS AGT 8000	20	20	40	8	8

8.2 Cable cross section

Fig. 8.2-1: Cable cross section

Length	1 - 3 m	4 - 6 m	7 - 10 m	11 - 15 m	16 - 20 m
16 mm ²	70 A	63 A	55 A	48 A	42 A
25mm ²	112 A	100 A	88 A	75 A	63 A
35mm ²	155 A	140 A	125 A	110 A	95 A
50mm ²	225 A	200 A	175 A	150 A	125 A
70mm ²	315 A	285 A	250 A	220 A	190 A
95mm ²	425 A	380 A	340 A	300 A	260 A
120mm ²	540 A	490 A	440 A	400 A	360 A

8.3 Trouble shooting

8.3.1 Generator Voltage too low

If the generator delivers undervoltage, there can be various reasons for this:

Cause	Solution
Generator is overloaded.	Reduce the electrical load. (Switch off load)
Motor is not reaching the rated rpm.	Refer to "motor faults" section.
Actuator is not in maximum position.	Check actuator resp. renew.
VCS-voltage controller defective or wrong adjusted.	Check resp. renew.

8.3.2 Generator voltage too high

The following reasons may be the cause, if the generator delivers overvoltage:

Cause	Solution
The engine is running at the wrong speed.	Check the speed of the motor with a rev or frequency counter, set the correct speed.
VCS-voltage controller defective or wrong adjusted.	Check resp. renew.
Actuator defective.	Check resp. renew.

8.3.3 Generator voltage fluctuates

Cause	Solution
1. Fault or defect on the load side. 2. A motor fault.	1. Check if the power requirement of the load fluctuates. 2. See "Motor running irregularly".

8.3.4 Motor does not turn over when starting

Cause	Solution
Battery main switch is switched off.	Check the position of the battery main switch, if necessary switch on..
Battery voltage not sufficient.	Check that connection is firm and whether corrosion has occurred..
Starting current fault.	The voltage of full batteries fall to a maximum of 11V. The wiring is severed if the voltage does not drop. The battery is discharged if the voltage drops further.

8.3.5 Motor turns over but does not start

Cause	Solution
Stop solenoid valve not opening.	Check wire connections and circuitry to solenoid valve. (ref. DC wiring diagram: Relay K2, Fuse)
Fuel pump does not operate.	Check fuel-filter and pump: clean if necessary.
Lack of fuel.	Check fuel supply.
Glow-plugs not working correctly.	Check glow plugs and heating time.
Too much air in fuel lines.	Test fuel system for leakage. Bleed air from fuel system (refer to section "Air-bleeding of the Fuel System").
Fuel filter blocked.	Replace fuel filter.
Low compression pressure.	See Kubota motor-manual.



8.3.6 Motor does not turn over at normal speed during the start process

Cause	Solution
Starter battery voltage insufficient.	Check battery.
Damaged bearing(s) piston (seized).	Repairs need to be carried out by Kubota-Service. (refer to Kubota motor-manual)
Cooling water in combustion chamber.	<ol style="list-style-type: none"> 1. Turn generator "OFF" at control panel. 2. Remove the glow plug (see Kubota-manual). 3. Rotate the motor by hand carefully. 4. Check if there is water in the oil and change both oil and filter if necessary. 5. Determine cause for excess water in the combustion chamber. The excess water can be caused by a defective air vent in the cooling water system, which should be checked and cleaned, or replaced if faulty.

8.3.7 Motor runs irregularly

Cause	Solution
Faulty centrifugal injector governor.	Have the centrifugal governor inspected by a Kubota-Service technician.
Too much air in fuel lines.	Bleed air from fuel system.

8.3.8 Motor speed drop down

Cause	Solution
Too much oil.	Drain oil.
Lack of fuel.	Check fuel supply system: <ul style="list-style-type: none"> - fuel filter, renew if necessary - check fuel pump - check fuel lines (bleed if necessary)
Lack of intake air.	Check air intake paths. Check and clean air filter (and intake muffler if installed).
Generator overloaded by too many load.	Reduce the electrical load (switch off load).
Generator overloaded by over-energizing.	Check that the proper capacitor type is installed and that they are connected correctly.
Defective generator (windings, bearings, or other).	Generator must be sent to manufacturer for repair of damaged bearings or winding.
Damaged engine.	Repair of bearing damage, etc., by Kubota-Service.

8.3.9 Motor switches itself off

Cause	Solution
Fuel solenoid valve or throttle shut solenoid is not switching off.	Check wire connections to solenoid. Check valve functions as in the "Inlet Fuel Solenoid Valve" or in the throttle shut off solenoid sections. Replace if necessary.



8.3.10 Motor stops by itself

Cause	Solution
Lack of fuel.	Check fuel supply system.
Excess heat in cooling system (thermo switch tripped)- lack of cooling water. Is indicated on the remote control panel.	Check cooling water system flow: water pump, inlet water filter, extra heat exchanger coolant flow.
Lack of oil (oil pressure sensor tripped).	Check oil-level and if necessary top up. Check motor's oil-pressure and have repaired by Kubota-Service if necessary.

8.3.11 Sooty black exhaust

Cause	Solution
Generator is overloaded.	Check electrical load and switch off unnecessary load.
Insufficient intake air.	Check intake air filter; clean if necessary.
Fuel injector nozzles faulty.	Replace injector nozzles.
Valve clearance incorrect.	Readjust valve clearance to correct value (refer to Kubota-manual).
Poor fuel quality.	Use better quality diesel (recommended: 2-D Diesel).
Poor combustion.	Incorrect AFR (air/fuel ratio) due to motor timing adjustment. Have motor serviced by Kubota.
Low compression pressure.	See Kubota motor manual.

8.3.12 Generator must be shut off immediatly if

Cause	Solution
<ul style="list-style-type: none"> - motor rpm suddenly rises or drops - unusual noise comes from genset - exhaust colour suddenly becomes dark - motor overheats - oil pressure drops, oil light suddenly flashes 	Refer to respective section of manual and if necessary, have repaired by Kubota-Service, or Panda representative.

8.3.13 Troubleshooting VCS system

Cause	Solution
Actuator does not move.	Check voltage supply and wire connections to actuator. Motor connected? Check connection to VCS.
Actuator sets throttle too high or too low.	Check that the wires to the actuator are connected properly (±). Check connection to VCS.
If the VCS electronics are faulty, the generator can still run by over-riding the system. To override the VCS, disconnect the plug and jumper the contacts. Loosen the connecting rods motor from the injection pump regulator and turn screw to a max. voltage of 33V.	



8.4 Technical Data Engine

Fig. 8.4-1: Technical Data Engine

	Panda AGT 8000 PMS
Type	D722
Govenour	VCS
Automatic startbooster	yes
Cylinder	3
Bore	67mm
Stroke	68mm
Stroke volume	719cm ³
max- power (DIN 6271-NB) at 3000 rpm	14,0kW
Rated speed 50Hz	3000rpm
Idle running speed ^a	2900rpm
Valve clearance (engine cold)	0,2mm
Cylinder head torque	42Nm
Compression ratio	23:1
Lubrication oil capacity	3,8l
Fuel consumption ^b	ca. 0,84 - 2,24 l
Oil consumption	max. 1% of fuel consumption
Cooling water requirement for seawater circuit	16-28l/min
Permissible max. permanent tilt of engine	a) 25° across the longitudinal axis b) 20° in the longitudinal direction


a. progressive speed by VCS

b. 0,35l/kW electrical power, the randomized values between 30% and 80% of the nominal power

8.5 Types of Coil

HP3 delta-connection


Fig. 8.5-1: HP3 delta -connection





HP3 star-connection

Fig. 8.5-2: HP3 star-connection



8.6 Engine oil

8.6.1 Engine oil classification

8.6.1.1 Operating range:

The operating range of an engine oil is determined by SAE class. "SAE" is for the union of American auto engineers (Society of Automotives Engineers).

The SAE class of an engine oil only informs over the viscosity of the oil (larger number = more viscous, smaller number = more highly liquidly) e.g. to 0W, 10W, 15W, 20, 30, 40. The first number shows the liquid of the oil with cold weather, the second number refers to the fluidity with heat. Complete yearly oils have usually SAE classes of SAE 10W-40, SAE 15W-40 etc..

8.6.1.2 Quality of oil:

The quality of an engine oil is specified by the API standard ("American Petroleum Institutes").

The API designation is to be found on each engine oil bundle. The first letter is always a C.

API C for diesel engines

The second letter is for the quality of the oil. The more highly the letter in the alphabet, the better the quality.

API C for diesel engine

Examples for diesel engine oil:

API CCEngine oil for small demands

API CDEngine oil for suction- and turbo diesel engine

API CFReplace the specification API CD since 1994

API CGEngine oil for highest demands, turbo-tested


For the Fischer Panda Generator the API CF Oil is needed.

Engine oil type	
over 25°C	SAE30 or SAE10W-30 SAE10W-40



Engine oil type	
0°C to 25°C	SAE20 or SAE10W-30 SAE10W-40
below 0°C	SAE10W or SAE10W-30 SAE10W-40

Fig. 8.6.1-1: Temp. range of the SAE classes



8.7 Coolant specifications

Use a mixture of water and antifreeze. The antifreeze needs to be suitable for aluminium. The antifreeze concentration must be regularly checked in the interests of safety.

Fischer Panda recommend to use the product: GLYSANTIN PROTECT PLUS/G 48

Engine coolant automotive industry Product description	
Product name	GLYSANTIN® PROTECT PLUS / G48
Chemical nature	Monoethylenglycol with inhibitors
Physical form	Liquid

Chemical and physical properties		
Reserve alkalinity of 10ml	ASTM D 1121	13 – 15 ml HCl 01 mol/l
Density, 20°C	DIN 51 757 procedure 4	1,121 – 1,123 g/cm ³
Water content	DIN 51 777 part 1	max. 3,5 %
pH-value undiluted		7,1 – 7,3

8.7.1 Coolant mixture ratio

Water/antifreeze	Temperature
70:30	-20°C
65:35	-25°C
60:40	-30°C
55:45	-35°C
50:50	-40°C

8.8 Fuel

Use a clean No. 2 Diesel fuel oil (SAE J313 JUN87) according to ASTM D975 and EN 590.

Do not use alternative fuel, because its quality is unknown or it may be inferior in quality. Kerosene, which is very low in cetane rating, adversely affects the engine.

8.8.1 Technical data generator with external rectifier unit

Fig. 8.8.1-1: Technical data generator with external rectifier unit

Generator	AGT 10000 PMS	AGT 11000 PMS	AGT 13000 PMS	AGT 18000 PMS	AGT 22000 PMS	AGT 25000 PMS
Generator type	PM-Synchronous Generator					
Winding type	AGT					
Wiring mode	3~					
Protection mode	IP 44					
Insulation class	H					
Nominal voltage	106 V					
Frequency	400 Hz					
Nominal speed	-> 3000 rpm					
Max. current	39,8 A	45,9 A	57,3 A	76,6 A	95,8 A	118 A
Apparent power	9,1 kVA	10,5 kVA	13,1 kVA	17,5 kVA	21,9 kVA	25 kVA
Real power	7,74 kW	8,93 kW	11,14 kW	14,88 kW	18,62 kW	21,25 kW
Power factor	0,85					
	Use only with rectifier unit AGT DC RU					

8.8.1.1 Technical Data Rectifier unit

Fig. 8.8.1.1-1: Technical Data Rectifier unit

Type	AGT DC RU 144V					
Power $P_{cont\ out}$	9,1 kW	10,5 kW	13,1 kW	17,5 kW	21,9 kW	24,5 kW
Output voltage U_{out}	165 V					
Output frequency F_{out}	DC					
Current max I_{max}	52 A	61 A	76 A	101 A	127 A	148 A
	Use only with AGT Generator					

The AGT-DC system consists of the AGT generator in conjunction with the rectifier unit named on the type plate and is only allowed in this combination! **ATTENTION!**



8.9 Technical data generator with internal rectifier unit

Fig. 8.9-1: Technical data generator

Type	S_{max} [kVA]	P_{max} [kW]	U_n [VDC]	I_{max} [A]	Nominal charging current [A]
AGT 2500-12	2,5	2,5	12	180	180



Type	Smax [kVA]	Pmax [kW]	Un [VDC]	I _{max} [A]	Nominal charging current [A]
AGT 2500-24	2,5	2,5	24	90	90
AGT 4000-12	4	3,2	12	220	280
AGT 4000-24	4	3,2	24	110	140
AGT 6000-12	5,5	4,8	12	290	360
AGT 6000-24	5,5	4,8	24	170	210
AGT10.000-24	10	8	24	290	360
AGT 10.000 48V	10	10	48V	170	
AGT 10.000 72V	10	10	72V	110	
AGT15.000-48	15	12	48	208	260
AGT20.000-48	20	16	48	290	360
AGT25.000-72	25	20	72	240	300
AGT25.000-144	25	21	144		
AGT30.000-96	30	24	96	208	260
AGT40.000-96	40	30	96	290	360

8.9.1 Technical data engine

Fig. 8.9.1-1: Technical data engine

Model	Kubota D 722	Kubota D 902	Kubota D 1105	Kubota D 1105 T	Kubota V 1505 T
Type	Vertical, water-cooled, 4-cycle diesel engine				
No. cylinders	3			4	
Bore [mm]	67	72	78		
Stroke [mm]	68	73,6	78,4		
Total displacement [ccm]	719	898	1123		1498
Combustion chamber	Spherical type (E-TVCS)				
SAE NET intermittent (SAE J1349) at 3600rpm [kW]	14,0	17,5	17,8	23,5	31,3
SAE NET continuous (SAE J1349) at 3600rpm [kW]	12,2	15,2	15,5	20,4	27,2
Maximum bare speed [rpm]	3800	3850	3200		
Minimum bare idling speed [rpm]	900 to 1000		850 to 950		800 to 900
Order of firing	1-2-3			1-3-4-2	
Direction of rotation	Counter-clockwise (viewed from flywheel side)				
Injection pump	Bosch MD type mini pump				
Injection pressure	13,73 MPa, 1991 psi (140kgf/cm ²)				
Injection timing (before T.D.C)	20°		18°		17°
Compression ratio	23,5 : 1	24 : 1		23 : 1	
Fuel	Diesel fuel No. 2-D				
Lubrication (API classification)	above CF grade				
Dimension (lengthxwidthxheight) [mm]	426x389x520	467x421x544	497,8x396x602	497,8x433x626	591,3x433x621
Dry weight (BB spec.) [kg]	63,1	72	93	97	114
Starting system	Cell starter (with glow plug)				
Valve clearance (engine cold) [mm]	0,145 to 0,185				
Cylinder head cover screw torque [Nm]	37,3 to 42,2		63,7 to 68,6		
Lubrication oil capacity [l] (oil pan)	3,2(101mm) 3,8l (121mm)	3,7(101mm)	5,1		6,7
Fuel consumption ^a [l]	0,96 - 2,55	1,10 - 2,94	1,38 - 3,67	1,84 - 4,90	2,3 - 6,1
Oil consumption	max. 1% of fuel consumption				
Permissible max. permanent tilt of engine	a) 25° across the longitudinal axis b) 20° in the longitudinal direction				

a. 0,35l/kW electrical power, the randomized values between 30% and 80% of the power rating.

Fig. 8.9.1-2: Technical data engine

Model	Kubota V2403				
Type	Vertical, water-cooled, 4-cycle diesel engine				
No. cylinders	4				
Bore [mm]	87				
Stroke [mm]	102,4				
Total displacement [ccm]	2434				
Combustion chamber	Spherical type (E-TVCS)				
SAE NET intermittent (SAE J1349) at 2600rpm [kW]	35,8				



Model	Kubota V2403				
SAE NET continuous (SAE J1349) at 2600rpm [kW]	31,1				
Maximum bare speed [rpm]	2800				
Minimum bare idling speed [rpm]	750-850				
Order of firing	1-3-4-2				
Direction of rotation	Counter-clockwise (viewed from flywheel side)				
Injection pump	Bosch MD type mini pump				
Injection pressure	13,73 MPa, 1991 psi (140kgf/cm ²)				
Injection timing (before T.D.C)	18°				
Compression ratio	23,8 : 1				
Fuel	Diesle fuel No. 2-D				
Lubrication (API classification)	above CD grade				
Dimension (lengthxwidthxheight) [mm]	670,9x499,0x684,5				
Dry weight (BB spec.) [kg]	184				
Starting system	Cell starter (with glow plug)				
Valve clearance (engine cold) [mm]	0,145 to 0,185				
Cylinder head cover screw torque [Nm]	37,3 to 42,2				
Lubrication oil capacity [l] (oil pan)	9,5 Liter				
Fuel consumption ^a [l]	0,96 - 2,55				
Oil consumption	max. 1% of fuel consumption				
Permissible max. permanent tilt of engine	a) 25° across the longitudinal axis b) 20° in the longitudinal direction				

a. 0,35l/kW electrical power, the randomized values between 30% and 80% of the power rating.




Fischer Panda Datenblatt / Datasheet

9. VCS-AGT-U/I**9.1 Delivery versions**

Art. No.	Art. Type
21.02.01.066H	VCS-AGT-U/I 12 V= @60 mV
21.02.01.070H	VCS-AGT-U/I 24 V= @60 mV
21.02.01.071H	VCS-AGT-U/I 36 V= @60 mV
21.02.01.072H	VCS-AGT-U/I 48 V= @60 mV
21.02.01.073H	VCS-AGT-U/I 72 V= @60 mV
21.02.01.074H	VCS-AGT-U/I 80 V= @60 mV
auf Anfrage / on request	VCS-AGT-U/I 96 V= @60 mV
21.02.01.075H	VCS-AGT-U/I 120 V= @60 mV
21.02.01.076H	VCS-AGT-U/I 144 V= @60 mV
21.02.01.077H	VCS-AGT-U/I 180 V= @60 mV
auf Anfrage / on request	VCS-AGT-U/I 300 V= @60 mV
auf Anfrage / on request	VCS-AGT-U/I 320 V= @60 mV
auf Anfrage / on request	VCS-AGT-U/I 336 V= @60 mV

9.2 Voltage control system

Fig. 9.2-1: VCS view




- 1. Terminals 7+8
- 2. Potentiometer for the charging voltage

- 3. Terminals 1-6
- 4. Programming



Fischer Panda Datenblatt / Datasheet

Fig. 9.2-2: Electronic Voltage Control



1. Terminals 9+10

2. Potentiometer for the charging current

The VCS control is used for the adjustment of the number of revolutions of the engine and thus the voltage of the generator. It belongs to the accessories and is externally attached.

Fig. 9.2-3: Terminals of the VCS

No.	Short mane	IN/OUT	Function
1	+ Actuaror	O	Out (+) for actuator
2	- Actuator	O	Out (-) for actuator
3	+12V	I	Operation voltage(+); 12V-Automotive
4	0V	I	Operation voltage(-); 12V-Automotive
5	AC Controllamp	O	to 0V - Optional
6	VCS on	I	12V: VCS is on / open : VCS is off
7	Mesurement voltage +	I	Mesurement voltage (+) from the generator
8	Mesurement voltage -	I	Mesurement voltage (-) from the generator
9	Mesurement current +	I	Mesurement current (+) from the generator
10	Mesurement current -	I	Mesurement voltage (-) from the generator

The potentiometer next to clamp 7/8 is needed for adustment of the measurement voltage and should be done by an service technican only.

The potentiometer next to clamp 9/10 is needed for adustment of the measurement current and should be done by an service technican only.

9.2.1 General working of the VCS

When the VCS is active (+12V on clamp 6) the VCS controls the actuator to reach the exact voltage.

The output current of the generator is seized over a shunt, with an output voltage of 60 mVs rated current. (The output voltage is linear to the output current).



Fischer Panda Datenblatt / Datasheet

9.3 Personal requirements

The described installation must be done by a technical trained person or a Fischer Panda service point. Safety instructions for the voltage control

9.3.1 Safety References concerning current

A broken cable in the measurement line will be notice by the VCS and the generator will slow down and stop.

NOTE!: Broken cable in the measurement line



A short-circuit in the measuring line or a wrong pole connection is not recognized by the VCS and is handled as “no voltage”.

Warning!: Short circuit in the measurement line

In this case the VCS is out of function. Therefore, it is necessary to check the right working of the VCS at the installation. Also a second overvoltage protection must be installed.



A shielded cable is needed for the measurement voltage.

NOTE!: Cable for the measuring line

The cable should not be longer than 5 meters. The shield should be connected to ground at one side.



Note the safety instruction in the generator manual!.



Fischer Panda Datenblatt / Datasheet

9.3.2 Checking of the VCS voltage control when the generator is not running

1. VCS-cable connected?
2. Cable for measuring voltage connected to the VCS?
3. Cable for current measuring input connected to the VCS?
4. Actuator spindle lubricated with anti-seize?

Requirements:

Checking the actuator

1. Disconnect clamp 50 at the starter
2. Switch the remote control panel on and press the start button.

As long as the relay of the starter is controlled, the VCS regulates the accelerator in the maximum position (over the starter motor). When the start relay is not active, the accelerator goes to zero (over the actuator).

Check the right working of the actuator.

Fig. 9.3.2-1: Clamp 50



9.3.3 Function of the VCS

The current regulation barrier can be finely adjusted over a potentiometer, which is accessible at the back of the VCS (+5 % / -24 %).

9.3.4 Checking the VCS voltage regulation


Connect clamp 50 to the starter motor again und start the generator. Control the battery voltage and check if the generator regulates the voltage. Check, if the generator regulates the voltage exactly by switching on and off load.

Readout potentiometer for the charging voltage

1. Potentiometer for setting the charging voltage

Turn to the right for increasing the charging voltage.

Fig. 9.3.4-1: Potentiometer charging voltage





Fischer Panda Datenblatt / Datasheet

9.3.5 Checking the current limiting

For this test an ampere plier is needed (DC or a multimeter mV/V) in order to control the generator output current, as well as a multimeter with a DC millivolt range. The batteries must be unloaded (avoid deep discharge of the batteries) to make sure, that the generator is able to supply the maximum output capacity. Keep the generator running and control the DC output current. Measure the voltage signal at the clamps 9 and 10 of the VCS cover by means of a multimeter, which measures millivolt. Check the polarity of this signal. With generators older than 2003, the maximum DC voltage is 60 millivolts. With generators from 2003 upwards the DC voltage is 48 millivolts - this is 80 % of the maximum permanent current. If this signal is exceeded, check the correct connection of the shunt signal cable and the polarity of the shunt signal to the VCS cover.

For setting the charging current resp. the voltage, load should be switched on with a nominal capacity of the generator. Now, the charging current must be measured and set to 100 amps by the potentiometer, in order to operate the engine in its nominal capacity range.


Readout potentiometer for the charging voltage

1. Potentiometer for setting the charging voltage

Turn to the right for increasing the charging voltage.

The factory setting is only to be changed by a technician.

Fig. 9.3-1: Potentiometer charging current





Leere Seite / Intentionally blank



Fischer Panda

Power - wherever you are

Manual



Generator Control Panel P6+

12V version - 21.02.02.046H

24V special version - 21.02.02.047H

Option automatic adapter - 21.02.02.016H

Option master-slave adapter - 21.02.02.015H

Fischer Panda GmbH



Current revision status P6+ manual

	Document
Actual:	Panel Generator Control P6+ RE0703_Kunde_eng.R06.1_18.2.11
Replace:	Panel Generator Control P6+ RE0703_Kunde_eng.R06

Revision	Page
Upgrade the whole manual	
Safety instruktion See valve added	
Hole pattern changed	
New display foil	

Copyright

Duplication and change of the manual is permitted only in consultation with the manufacturer!

Fischer Panda GmbH, 33104 Paderborn, reserves all rights regarding text and graphics. Details are given to the best of our knowledge. No liability is accepted for correctness. Technical modifications for improving the product without previous notice may be undertaken without notice. Before installation, it must be ensured that the pictures, diagrams and related material are applicable to the genset supplied. Enquiries must be made in case of doubt.



10. Safety Instructions Generator Control P6+

10.1 Personal requirements


The settings described here can be performed by the operator, unless otherwise indicated.

The installation should be carried out by specially trained personnel or by authorized repair shops (Fischer Panda service points).

10.2 Safety instructions for this chapter

Follow the general safety instruction at the front of this manual. **Note!:**

If these not exist, they can be requested at Fischer Panda GmbH, 33104 Paderborn.



Danger for life! - The generator can be equipped with an automatic start device. This means the generator can be started by an external signal. To avoid an unexpected starting of the generator, the starter battery must be disconnected before starting at the generator.

Warning!: Automatic start



The generator must not be put into operation with cover removed

If the generator is mounted without sound cover, the rotating parts (pulley, belt, etc.) must be covered and protected so that an injury is excluded.

All service, maintenance or repair work on the unit may be made only while the motor is off.

Warning!:



Danger for Life. Improper handling, operation, installation and maintenance can result in severe personal injury and/or material damage.

Electrical voltages above 48 volts (battery chargers greater than 36 volts) are always dangerous to life. The rules of the respective regional authority must be adhered to. Only an electrician may carry out installation of the electrical connections for safety reasons.

Warning!: Danger of Life - High voltage



Disconnect the battery when working on the generator

The battery must always be disconnected (first negative then positive pole), when work on the generator or the electrical system of the generator are made, so that the generator can not be started accidentally.

This is especially true for systems with an automatic start function. The automatic start function is to be deactivated before the work.


Attention!:



Sea valve must be closed. (only PMS version)

Note also the safety of the other components of your system.

Note!:






11. General operation

11.1 Panel Generator Control

Fig. 11.1-1: Panel front



- 01. LED for coolant temperature red¹
- 02. LED for waterleak red/yellow¹ (sensor optional)
- 03. LED for AC-voltage fault red/yellow¹
- 04. LED for AC-voltage ok green¹
- 05. LED for winding temperature red¹
- 06. LED for oil pressure red¹
- 07. LED for battery charge voltage fault green/red¹

- 08. LED for pre-glow „heat“ orange¹
- 09. LED for Generator „start“ green¹
- 10. LED for Generator „stand-by“ green¹
- 11. Push button for pre-glow „heat“
- 12. Push button for Generator „start“
- 13. Operating hours counter
- 14. Push button panel „off“
- 15. Push button panel „on“


Fischer Panda Art. No. 21.02.02.009H

¹ LED green: normal operation mode, LED red: fault, LED yellow: warning, LED orange: active



11.2 Rear view 12V-version

Fig. 11.2-1: Panel rear view 12V-version




- 01. Control board
- 02. Terminal block (master-slave adapter: left row; automatic adapter: right row)
- 03. Terminals 1-12 (see Kapitel 11.4.2, "Terminal connections," auf Seite 148)
- 04. Fuse 630mA slow-blow

Fischer Panda Art. No. 21.02.02.009H



11.3 Rear view 24V-version

Fig. 11.3-1: Panel rear view 24V-version



- 01. Control board
- 02. Terminal block (master-slave adapter: left row; automatic adapter: right row)
- 03. Fuse 630mA slow-blow
- 04. Terminals 1-12 (see Kapitel 11.4.2, "Terminal connections," auf Seite 148)
- 05. Linear controller 24V
- 06. Linear controller 24V

Fischer Panda Art. No. 21.02.02.012H

11.4 Installation of the remote control panel

11.4.1 Placement.

Install the remote control panel at a dry, good accessible and shady place.

Connect the remote control panel to the standard 12 core cable at the generator. (1:1)

11.4.2 Terminal connections

Standard for NC temperature switch configured i.e. in case of failure „open“.

Fig. 11.4.2-1: Terminal connections

Clamp no.	Clamp name	IN / OUT	Description
1	Vbat	IN	power supply + 12V (or optional 24V, must be adjusted by jumper)
2	GND	IN	power supply -
3	T-Engine	IN	Error "coolant temperature". Input for thermo-switch to GND. The input is adjustable for NC/NO (N = no error) (must be adjusted by solder Jumper). The input loads the switch with $\geq 22\text{mA}$ to +12V (with 24V-operated internally generated). The occurrence of an error is delayed, for analysis and displayed, around 100ms. Omission not. The in/out status is indicated with red LED.
4	Water leak (Replace air filter)	IN	Error "water leak". Input for sensor switch to GND. The input is adjustable for NC/NO (N = no error) (must be adjusted by solder Jumper). The input loads the switch with $\geq 10\text{mA}$ to +12V (with 24V-operated internally generated). The occurrence of an error is delayed, for analysis and displayed, around 100ms. Omission not. The input status is indicated with red LED. The input can be used alternatively for the signal "Replace air filter" (must be adjusted by solder Jumper). Then the signal does not lead to switching off and is indicated with yellow LED.
5	Oil-Press	IN	Error "oil pressure". Input for oil pressure switches to GND. The input is adjustable for NC/NO (N = no error) (must be adjusted by solder Jumper). The input loads the switch with $\geq 22\text{mA}$ to +12V (with 24V-operated internally generated). The occurrence of an error is delayed, for analysis and displayed, around 1s. Omission not. The input status is indicated with red LED.
6	DC-Control	IN / OUT	Load control display. Input for signal of the dynamo. The input is adjustable for GND = OK or 12V/24V = OK (must be adjusted by solder Jumper). The input loads the signal with 5mA at 12V and 10mA at 24V. The input status is indicated with red and green LED. The connection can supply an energizing current for the dynamo over a fixed resistor with 68R. Either with the control panel switched on or with "Fuel pump" switched on (must be adjusted by solder Jumper). This function is available only in 12V-operation.
7	AC-Control	IN	AC control display. Input for NC-open-collector-sensor-switch to GND (N = OK). The input loads the switch with $\geq 2,5\text{mA}$ to +12V (with 24V-operated internally generated). The input status is indicated with red and green LED's.
8	Heat	OUT	Output for pre-glow relays. The output is so long active, as the button "Heat" is pressed. The output supplies, if active, the voltage of clamp 1. Additionally the output can be operated via the button "start" (must be adjusted by solder Jumper). Consider (notes 1-4).
9	Fuel-Pump	OUT	Output for fuel pump relay. The output is active, if no error is present (inputs 3, 4, 5, 11 and 12, if configured accordingly). The button "start" suppresses the error analysis and the output is then also active in the case of error, if the button "start" is pressed. The output supplies, if active, the voltage of clamp 1. Consider (notes 1-4).
10	Start	OUT	Output for starting relay. The output is active, as long as the button "start" is pressed. The output supplies, if active, the voltage of clamp 1. Consider (notes 1-4).

11	AC-Fault (Fuel Level) [former T-Oil]	IN	<p>Error generator AC input for NC-open-collector-sensor-switch to GND (N = no error). The input loads the switch with $\geq 2,5\text{mA}$ to +12V. (with 24V-operated internally generated). The occurrence of an error is delayed, for analysis and displayed, around 100ms. Omission not. The input status is indicated with red LED.</p> <p>The input can be used alternatively for the signal "Fuel level" (must be adjusted by solder Jumper). The signal does not lead to switching off and is indicated with yellow LED.</p> <p>The input can be used alternatively for the signal "error oil-temperature". The input is adjustable for NC/NO (N = no error) (must be adjusted by solder Jumper). The load of the sensor switch is adjustable to $\geq 10\text{mA}$ by +12V (must be adjusted by solder Jumper).</p>
12	T-Winding	IN	<p>Error "winding temperature". Input for thermo-switch to GND. The input is adjustable for NC/NO (N = no error) (must be adjusted by solder Jumper). The input loads the switch with $\geq 22\text{mA}$ to +12V (with 24V-operated internally generated). The occurrence of an error is delayed, for analysis and displayed, around 100ms. Omission not. The input status is indicated with red LED.</p>

Notes:

Power rating of the output: max. 0,5A in continuous operation and briefly 1,0A.

The supply of all output currents may not exceed (less 0,2A power consumption) the rated current of the safety device of the control panel.

The output has a free wheeling diode, which short circuits negative voltages (related to GND).

The output has a Z-diode, which prevents a supply of positive voltage (related to GND) into the output.

11.4.3 Function of the jumpers

Fig. 11.4.3-1: Function of the solder jumper

Jumper	Status	Description
J1	closed	during operation of the start button heat is along-operated
	open	Function deactivated
J3	1-2	Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3	Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	Dynamo excitation resistor is deactivated
J101	closed	12V - operation
	open	24V - operation (optional)
J201	1-2	T-Engine-input, for contact, which opens in case of error (2)
	2-3	T-Engine-input, for contact, which closes in case of error (2)
J202	1-2	Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2	Oil-Press-input, for contact, which opens in case of error (2)
	2-3	Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2	AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3	AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2	T-Winding-input, for contact, which opens in case of error (2)
	2-3	T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	Input Water leak has red LED and switches off
	2-3	Input Water leak has yellow LED and does not switch off
J207	1-2	Input AC-Fault has red LED and switches off
	2-3	Input AC-Fault has yellow LED and does not switch off
J208	1-2	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	DC-Control-Signal (+) = OK three-phase DC-alternator



J209	1-2	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed	Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.

11.4.4 Configuration and adjustment

11.4.4.1 Configuration and setting sheet KE01

Standard jumpering for generators with three-phase DC-alternator (Kubota Super 5 series).

Panel only for 12V-operation.

The safety device is installed with the value 0,63AT.

The circuit parts for 24V-operation are not equipped.

Fig. 11.4.4.1-1: Settings of soldered jumper for this configuration (column Conf.)

Jumper	Status	Conf.	Description
J1	closed		during operation of the start button heat is along-operated
	open	X	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	X	Dynamo excitation resistor is deactivated
J101	closed	X	12V - operation
	open		24V - operation (not possible)
J201	1-2	X	T-Engine-input, for contact, which opens in case of error (2)
	2-3		T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	X	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2	X	Oil-Press-input, for contact, which opens in case of error (2)
	2-3		Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2	X	AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3		AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2	X	T-Winding-input, for contact, which opens in case of error (2)
	2-3		T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	X	Input Water leak has red LED and switches off
	2-3		Input Water leak has yellow LED and does not switch off
J207	1-2	X	Input AC-Fault has red LED and switches off
	2-3		Input AC-Fault has yellow LED and does not switch off
J208	1-2		DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	X	DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2		DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	X	DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	X	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68 Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.

11.4.4.2 Configuration and setting sheet KE02

Standard jumpering for generators with three-phase DC-alternator.

Panel for 24V-operation (over attitude of solder jumper J101 alternatively 12V-operation is possible).

The safety device is installed with the value 0,63AT.

The circuit parts for 24V-operation are not equipped.

Fig. 11.4.4.2-1: Einstellung der Lötjumper für diese Konfiguration (Spalte Konf.)

Jumper	Status	Conf.	Description
J1	closed		during operation of the start button heat is along-operated
	open	X	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	X	Dynamo excitation resistor is deactivated
J101	closed		12V - operation
	open	X	24V - operation
J201	1-2	X	T-Engine-input, for contact, which opens in case of error (2)
	2-3		T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	X	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2	X	Oil-Press-input, for contact, which opens in case of error (2)
	2-3		Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2	X	AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3		AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2	X	T-Winding-input, for contact, which opens in case of error (2)
	2-3		T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	X	Input Water leak has red LED and switches off
	2-3		Input Water leak has yellow LED and does not switch off
J207	1-2	X	Input AC-Fault has red LED and switches off
	2-3		Input AC-Fault has yellow LED and does not switch off
J208	1-2		DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	X	DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2		DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	X	DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	X	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68 Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.



11.4.4.3 Configuration and setting sheet KE03

Standard jumpering for generators with DC-alternator.

Panel only for 12V-operation.

The safety device is installed with the value 0,63AT.

The circuit parts for 24V-operation are not equipped.

Fig. 11.4.4.3-1: Einstellung der Lötjumper für diese Konfiguration (Spalte Konf.)

Jumper	Status	Konf.	Description
J1	closed		during operation of the start button heat is along-operated
	open	X	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	X	Dynamo excitation resistor is deactivated
J101	closed	X	12V - operation
	open		24V - operation (not possible)
J201	1-2	X	T-Engine-input, for contact, which opens in case of error (2)
	2-3		T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	X	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2	X	Oil-Press-input, for contact, which opens in case of error (2)
	2-3		Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2	X	AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3		AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2	X	T-Winding-input, for contact, which opens in case of error (2)
	2-3		T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	X	Input Water leak has red LED and switches off
	2-3		Input Water leak has yellow LED and does not switch off
J207	1-2	X	Input AC-Fault has red LED and switches off
	2-3		Input AC-Fault has yellow LED and does not switch off
J208	1-2	X	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3		DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2	X	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3		DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	X	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.

11.4.4.4 Configuration and setting sheet KE04

Standard jumpering for generators with DC-alternator.

Panel for 24V-operation (over attitude of solder jumper J101 alternatively 12V-operation is possible).

The safety device is installed with the value 0,63AT.

The circuit parts for 24V-operation are not equipped.

Fig. 11.4.4.4-1: Einstellung der Lötjumper für diese Konfiguration (Spalte Konf.)

Jumper	Status	Konf.	Description
J1	closed		during operation of the start button heat is along-operated
	closed	X	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	closed	X	Dynamo excitation resistor is deactivated
J101	closed		12V - operation
	closed	X	24V - operation
J201	1-2	X	T-Engine-input, for contact, which opens in case of error (2)
	2-3		T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	X	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2	X	Oil-Press-input, for contact, which opens in case of error (2)
	2-3		Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2	X	AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3		AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2	X	T-Winding-input, for contact, which opens in case of error (2)
	2-3		T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	X	Input Water leak has red LED and switches off
	2-3		Input Water leak has yellow LED and does not switch off
J207	1-2	X	Input AC-Fault has red LED and switches off
	2-3		Input AC-Fault has yellow LED and does not switch off
J208	1-2	X	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3		DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2	X	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3		DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	X	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68 Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.



11.5 Starting preparation / Checks (daily)

11.5.1 Marine version

1. Oil level control (ideal level: 2/3 MAX).

The level should be about 2/3 of the maximum level of a cold engine.

Further, if installed, the oil level of the oil-cooled bearing must be controlled before each start - see sediment bowl at generator front cover!.

2. State of cooling water.

The external expansion tank should be filled up to 1/3 of the maximum in a cold state. It is very important that a large expansion area remains above the cooling water level.

3. Check if sea cock for cooling water intake is open.

For safety reasons, the sea cock must be closed after the generator has been switched off. It should be re-opened before starting the generator.

4. Check raw water filter.

The raw water filter must be regularly checked and cleaned. The impeller fatigue increases, if residual affects the raw water intake.

5. Visual inspection.

Control fixing bolts, check hose connectors for leakages, control electrical connections.

6. Switch off the load.

The generator should only be started without load.

7. Open fuel valve, if installed.

8. Close battery main switch (switch on).

11.5.2 Vehicle version

1. Oil level control (ideal level: 2/3 MAX).

The level should be about 2/3 of the maximum level of a cold engine.

Further, if installed, the oil level of the oil-cooled bearing must be controlled before each start - see sediment bowl at generator front cover!.

2. State of cooling water.

The external expansion tank should be filled up to 1/3 of the maximum in a cold state. It is very important that a large expansion area remains above the cooling water level.

3. Visual inspection.

Control fixing bolts, check hose connectors for leakages, control electrical connections.

4. Switch off the load.

The generator should only be started without load.

5. Open fuel valve, if installed.

6. Close battery main switch (switch on).

11.6 Starting and stopping the generators

11.6.1 Starting the generator

Danger for life! - The generator can be equipped with a automatic start device. This means the generator can be started by an external signal. To avoid an unexpected starting of the generator, the starter battery must be disconnected before start working at the generator.

Warning!: Automatic start



1. Press button „on“ (switch on).
LED for "on" = green.

Fig. 11.6.1-1: Panel on



2. Press button „heat“ (preglow engine).

LED for "heat" = orange.

Depending upon engine type and execution pre-heating can be necessary. Pre-heat is necessary at an operating temperature <20°C.

Fig. 11.6.1-2: Preglow



3. Press button „start“ (start engine).

LED for "start" = green.

The electric starter may only be used for a maximum of 20 seconds. Thereafter, a pause of at least, 60 seconds is required. If the genset does not immediately start, then the fuel intake should be checked to ensure it is flowing freely. (For temperatures below - 8°C check whether there is winter fuel)

4. Switch on load.

The load should only be switched on if the generator voltage is within the permissible range. Parallel connection of several loads should be avoided, especially if there are loads with electric motors, such as air-conditioning units in the system. In this case, the load must be connected Step by Step.

Fig. 11.6.1-3: Start





In the event of starting problems, close the sea water inlet cock. Panda marine generators only.

Should there be any reason to turn the engine (over) or start the engine i.e. to bleed the fuel system, the sea water inlet cock must be closed! During the starting process, the cooling water pump is driven with the motor. The cooling water is discharged to the exhaust outlet and, since the motor has not run, the exhaust pressure is not high enough to expel the sea water which has been brought to the exhaust outlet. To avoid filling the exhaust outlet with water and causing further problems, close the inlet sea water valve.

Once the engine is running, be sure to open the inlet valve!

Attention!:



11.6.2 Stopping the generator

1. Switch off load.
2. Recommendation: With turbo engines and during load more than highly 70% of the rated output, stabilize generator temperature at least 5 minutes with load switched off.

At higher ambient temperatures (more than 25°C) the generator should always run for at least 5 minutes without load, before it is switched off, regardless of the load.

3. Press button „off“ (switch off).
LED for "on" = off.

Fig. 11.6.2-1: Stop



Never switch off the battery until the generator has stopped, if necessary close fuel valve!


Attention!:





11.7 Automatic adapter - optional

Fig. 11.7-1: Panel 21.02.02.009H with Automatic adapter 21.02.02.016H



- 01. Main terminals
- 02. Automatic adapter 21.02.02.016H
- 03. 8-pole DIP-switch

Fischer Panda Art. No. 21.02.02.016H

11.7.1 Function:

The automatic adapter RE0704 extends the generator control panel P6+ with an automatic input. A potential-free contact can be attached to this input. If this contact is closed, then the generator, which is attached to the generator control panel P6+, is started automatically. If the contact is opened, then the generator is stopped automatically.

The automatic starting procedure consists of pre-heating (heat) and operating the starter (start). It can be again aborted at any time by opening the contact at the automatic input.

For automatic stopping (stop) the output "Fuel pump" (clamp 9 generator control panel) is switched off. The time for the automatic stop procedure can be terminated only by switching off generator control panel prematurely.

The times for "heat", "start" and "stop" are separately adjustable (see below).

The additional automatic adapter switched on and off using the generator control panel with its push buttons "on" and "off".

If the contact at the automatic input is connected, while the generator control panel is switched on, then the automatic starting procedure is carried out.

If the power supply is attached or switched on using the generator control panel, while the contact of the automatic input is closed, then the automatic starting procedure won't be carried out, because the generator control panel is always switched off after attaching the power supply (generator the control panel must have been separate from the power supply for at least 60s).

11.7.2 The mechanism entrance:

With (-) characterized connection is connected to GND.



With (+) characterized connection is the input.

The input is connected through a resistance to 12V (with 24V-operated internally generated). If the two connections are short circuited over a potential-free contact, then the input current flows.

To be considered for an electronic contact the low input current and the polarity is to be selected.

The high input current is to be selected for an electromechanical contact.

The input is debounced (delay time approx.1s).

On the input an external voltages must not be set.

Fig. 11.7.2-1: Data

Data:	
Parameter	Information
Operation voltage	The automatic adapter power is supplied via the generator control panel P6+. The same absolute maximum ratings obtain as with the generator control panel P6+.
Operation temperature	The same absolute maximum ratings obtain as with the generator control panel P6+.
Proper power consumption	10mA - 20mA
Tolerance of times	± 10%

Fig. 11.7.2-2: Settings

8-pole DIP-switch S1 settings (S1.1 to S1.8):										
		standard	S1.1	S1.2	S1.3	S1.4	S1.5	S1.6	S1.7	S1.8
Heat-time	2,5s		OFF	OFF						
	5s		ON	OFF						
	10s	X	OFF	ON						
	20s		ON	ON						
Start-time	8s	X			OFF					
	16s				ON					
Stop-time	16s					OFF	OFF			
	32s	X				ON	OFF			
	64s					OFF	ON			
	128s					ON	ON			
Operation-mode	Normal	X						OFF		
	Test (all times over 16)							ON		
Input current	1,25mA									OFF
	7mA	X								ON

The automatic adapter must only be used together with a device. The starter should only be switched on when the generator stationary (shut-down)!

Attention:





11.7.3 Terminal connections

Connection for the automatic adapter X2 (row with odd pin numbers // I/O viwe from operating panel)

Fig. 11.7.3-1: Terminal connections automatic adapter

Pin-no.	Pin-name	I / O	Description
1	VBF	O	power supply + (operation voltage behind fuse)
3	GND	O	power supply - (ground)
5	VBFS	O	power supply + switched (voltage Pin 1, with panel switched on)
7	12V	O	power supply + switched, at 12V-operation over closed soldered jumper J101 connected with VBFS (at optional 24V-operation: VBFS over internal voltage regulator at 12,9V regulated)
9	GND	O	power supply - (ground)
11	GND	O	power supply - (ground)
13	/Heat-signal	I	Heat is active, if the input is switched to GND
15	/Start-signal	I	Start is active, if the input is switched to GND
17	GND	O	power supply - (ground)
19	GND	O	power supply - (ground)
21	GND	O	power supply - (ground)
23	GND	O	power supply - (ground)
25	GND	O	power supply - (ground)
27	/Stop-signal	I	The Fuel pump signal is switched off, as long as the input is switched to GND, (also when starting)
29	FP-Int	O	Fuel pump signal internally, decoupled over diode from external signal
31	/Fault-signal	O	Output is switched to GND, if an error is present (inputs 3, 4, 5, 11 and 12, if configured and generally for 2s, after switching on the panel)
33	GND	O	power supply - (ground)




11.8 Master-Slave adapter - optional

11.8.1 Fischer Panda Art. No. 21.02.02.015H

12V-version

Fig. 11.8.1-1: Panel 21.02.02.009H with master-slave adapter 21.02.02.015H




- 01. Main terminals
- 02. Master-slave adapter 21.02.02.015H

11.8.2 Fischer Panda Art. No. 21.02.02.01H

24V-version

Fig. 11.8.2-1: Panel 21.02.02.012H with master-slave adapter 21.02.02.015H



- 01. Main terminals
- 02. Master-slave adapter 21.02.02.015H

With the Master-Slave-Adapter RE0706 two Generator Control Panels P6+ RE0703 can be connected to a Master-Slave-Combination. In addition on each Generator Control Panel P6+ an Master-Slave-Adapter RE0706 is installed. The Generator Control Panel P6+ is interconnected by the 14pole connecting terminals on the Master-Slave-Adapters 1:1. The Master-Panel is hereby defined when the generator is connected to the main connector. Thus, the main connector of the Slave-Panel should not be occupied (unconnected).

The solder jumpers on the Master-Panel have to be coded in the same manner as for a Master-Panel without a Slave-Panel as in normal operation. The solder jumpers on the Slave-Panel are coded as for slave operation (please see the appropriate adjustment pages for the Generator Control Panel P6+ RE0703).

The Master-Panel and Slave-Panel are identical, and only differs as a result of the coding. Both Master-Slave-Panels are also identical.

11.8.3 Terminal Connections:

X2: (14polig, 21 - 34) master Slave connection (1:1 wire)

X3: (2polig, 35 - 36) 35: Panel on signal of the Generator Control Panel P6+ RE0703

36: Error signal of the Generator Control Panel P6+ RE0703

The Panel-ON-Signal is active when the panel is switched on.

The error signal is so long active, as the panel recognizes an error, which must lead to switching the generator off.

The output voltage corresponds to the operating voltage of the Generator Control Panel P6+ less 0,7V - 1,4V. Each output has a free wheeling diode which short circuits externals voltage supplies under 0V and a decoupling diode which decouples the circuitry from external power feeding.

11.8.4 Fuse:

A 0,8AT fuse must be installed on the Master-Panel.

11.8.5 Terminal connections

11.8.5.1 Terminal X2 (IN/OUT from view Master-Operating-Panel)

Fig. 11.8.5-1: Terminal connections terminal X2 (IN/OUT from the view of the master-control-panel)

Pin-No.	Pin-name	IN / OUT	Description
21	VBF	O	power supply + (operation voltage behind fuse 12Vdc or 24Vdc depending on system)
22	GND	O	power supply - (ground)
23	ON-Signal	I / O	Panels are switched on, if the connection is switched using a push button (on master or slave) to VBF
24	OFF-Signal	I / O	Panels are switched off, if the connection is switched using a push button (on master or slave) to VBF
25	/Heat-Signal	I / O	Heat is active, if the connection is switched over a push button (on master or Slave) to GND
26	/Start-Signal	I / O	Start is active, if the connection is switched over a push button (on master or Slave) to GND
27	LED-T-Engine	O	Output for LED T-Engine on the Slave panel, is switched to GND, if the LED is illuminated
28	LED-Water-leak (Replace Airfilter)	O	Output for LED Waterleak on the Slave panel, is switched to GND, if the LED is illuminated
29	LED-Oil-Press	O	Output for LED Oil-Press on the Slave panel, is switched to GND, if the LED is illuminated



30	LED-AC-Fault (Fuel Level)	O	Output for LED AC-Fault on the Slave panel, is switched to GND, if the LED is illuminated
31	LED-T-Winding	O	Output for LED T-Winding on the Slave panel, is switched to GND, if the LED is illuminated
32	DC-Control	O	Output for LED DC-Control-display on the Slave panel. The DC control signal is ground through 1:1.
33	AC-Control		Output for LED AC-Control-display on the Slave panel. The AC control signal is ground through 1:1.
34	VBFS	O	power supply + switched (otherwise like 21, VBF)

The use of these connections for other purposes, other than the master-slave connection of two generator control panels, is generally forbidden. In individual cases, after consultation and clarifying the technical details, a release for another use can, if technically possible, be allowed.

11.8.5.2 Terminal X3

Fig. 11.8.5.2-1: Terminal connections terminal X3

Pin-No.	Pin-name	IN / OUT	Description
35	Panel ON	O	With panel (ON/OFF) switched voltage of clamp X2.1 (VBF). (Consider notes 1-4)
36	Error	O	Output is switched on, if a ceitical error is present. (Consider notes 1-4)

Notes:

1. Power rating of the output: max. 0,5A in continuous operation and briefly 1,0A.
2. The supply of all output currents may not exceed (less 0,2A power consumption) the rated current of the safety device of the control panel.
3. The output has a free wheeling diode, which short circuit negative voltages (related to GND).
4. The output has a Z-diode, which prevents an overvoltage (related to GND) into the output.

11.8.6 Configuration and adjustment

11.8.6.1 Configuration and setting sheet KE05

Standard Jumperung for use as Slave-Panel in connection with **two** Master-Slave-Adapters RE0706 and a Generator Control Panel P6+ RE0703 as Master-Panel. Panel only for 12V-Betrieb.

The safety device is installed with the value 0,63AT. The circuit parts for 24V-operation are not equipped.

Fig. 11.8.6-1: Settings of soldered jumper for this configuration (column Conf.)

Jumper	Status	Conf.	Description
J1	closed		during operation of the start button heat is along-operated
	open	XM	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	XM	Dynamo excitation resistor is deactivated
J101	closed	M	12V - operation
	open	M	24V - operation (not possible)
J201	1-2		T-Engine-input, for contact, which opens in case of error (2)
	2-3	XM	T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	XM	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2		Oil-Press-input, for contact, which opens in case of error (2)
	2-3	XM	Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2		AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3	XM	AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2		T-Winding-input, for contact, which opens in case of error (2)
	2-3	XM	T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	M	Input Water leak has red LED and switches off
	2-3	M	Input Water leak has yellow LED and does not switch off
J207	1-2	M	Input AC-Fault has red LED and switches off
	2-3	M	Input AC-Fault has yellow LED and does not switch off
J208	1-2	M	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	M	DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2	M	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	M	DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	XM	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

X = Jumper must be so set

XM = Jumper, function must be so set on the master panel is selected

M = Jumper must be set exactly the same, as on the master panel,

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68 Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.



11.8.6.2 Configuration and setting sheet KE06

Standard jumpering for use as Slave-Panel in connection with **two** Maste-Slave-Adapters RE0706 and a Generator Control Panel P6+ RE0703 as Master-Panel. Panel for 24V-operation. (over attitude of solder jumper J101 alternatively 12V-operation is possible)

The safety device is installed with the value 0,63AT.

The circuit parts for 24V-operation are not equipped.

Fig. 11.8.6.2-1: Settings of soldered jumper for this configuration (column Conf.)

Jumper	Status	Conf.	Description
J1	closed		during operation of the start button heat is along-operated
	open	XM	Function deactivated
J3	1-2		Dynamo excitation resistor 68R is switched on with Fuel-Pump (1)
	2-3		Dynamo excitation resistor 68R is switched on with Panel-ON (1)
	open	XM	Dynamo excitation resistor is deactivated
J101	closed	M	12V - operation
	open	M	24V - operation
J201	1-2		T-Engine-input, for contact, which opens in case of error (2)
	2-3	XM	T-Engine-input, for contact, which closes in case of error (2)
J202	1-2		Water leak-input / Replace air filter, for contact, which opens in case of error (2)
	2-3	XM	Water leak-input / Replace air filter, for contact, which closes in case of error (2)
J203	1-2		Oil-Press-input, for contact, which opens in case of error (2)
	2-3	XM	Oil-Press-input, for contact, which closes in case of error (2)
J204	1-2		AC-Fault-input / Fuel level, for contact, which opens in case of error (2)
	2-3	XM	AC-Fault-input / Fuel level, for contact, which closes in case of error (2)
J205	1-2		T-Winding-input, for contact, which opens in case of error (2)
	2-3	XM	T-Winding-input, for contact, which closes in case of error (2)
J206	1-2	M	Input Water leak has red LED and switches off
	2-3	M	Input Water leak has yellow LED and does not switch off
J207	1-2	M	Input AC-Fault has red LED and switches off
	2-3	M	Input AC-Fault has yellow LED and does not switch off
J208	1-2	M	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	M	DC-Control-Signal (+) = OK three-phase DC-alternator
J209	1-2	M	DC-Control-Signal (-) = OK dynamo 12V at Kubota Z 482 / D 722 engines
	2-3	M	DC-Control-Signal (+) = OK three-phase DC-alternator
J210	closed		Input AC-Fault has Pull-Up-current $\geq 10\text{mA}$
	open	XM	Input AC-Fault has Pull-Up-current $\geq 2,5\text{mA}$

The solder jumpers are marked on the printed circuit board (with jumper no. and at three-part solder jumper with soldering surface no.)

X = Jumper must be so set

XM = Jumper, function must be so set on the master panel is selected

M = Jumper must be set exactly the same, as on the master panel,

(1): Equivalent resistance for load control lamp e.g. for use with three-phase alternator also integrated automatic controller of Bosch. The resistance value is 68 Ω 3W, i.e. only for 12V.

(2): A closed contact switches the appropriate input to GND.






12. Measurements

12.1 Hole pattern

Fig. 12.1-1: Hole pattern





Leere Seite / Intentionally blank