

UK SCANGRIP POWERBANK

WARNING / CHARGING INSTRUCTIONS / BATTERY TIPS

- Do not use the powerbank near a naked flame
- Before using the powerbank for the first time, the battery must be fully charged
- Recharge frequently
- Always replace the battery with an original SCANGRIP battery
- Do not leave the battery without charge for an extended period - deep discharge can damage the battery

ELECTRICAL SPECIFICATIONS:

- Charger voltage	5 V
- Rated charging current	2 A
- Output voltage	5 V
- Output current rating	2 A
- Output short circuit protection	Yes

USE:


- When a device is connected to the USB output, the powerbank will turn on.
- When no device is connected, the power bank will shut down automatically.
- When the power bank is on, the battery status LEDs will turn on in the following pattern:



- When there is less than 25% battery capacity left, the last LED will flash.

CHARGING:

- When the powerbank is charging, the LEDs will light red in the following pattern



- When the powerbank is fully charged, the LEDs will turn green.
- When the powerbank is off. Press and hold the power button for 2 seconds to read the remaining battery capacity. The LEDs will turn off automatically after 2 seconds.
- When the battery has less than 25 % capacity left, the last LED will flash.



Discarded electrical products must not be disposed of together with household waste. Please use recycling facilities. Ask your local authority or retailer for advice on recycling.

- The battery must be removed from the device before it is broken up
- The device must be disconnected from the mains when the battery is removed
- Please dispose of the battery safely