UK I-VIEW

WARNING / CHARGING INSTRUCTION / BATTERY TIPS

- Avoid looking directly into the beam of light, as this will result in dazzling
- Do not use the lamp near a naked flame
- Recharge frequently
- Do not leave the battery without charge for an extended period Deep discharge risks damaging the battery
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced

USE

To turn the I-VIEW On or Off, press the power button.

CHARGING

- The I-VIEW has 4 battery status LEDs.
- When the I-VIEW is charging, the LEDs will light red in the following pattern



- When the I-VIEW is off. Press and hold the power button for 2 seconds to read the remaining battery capacity.
- When the battery has less than 25 %, the last LED will flash.



- When the charger is connected the I-VIEW will turn off.
- If the I-VIEW is turned on while charging, the charging will stop. Charging will resume when the I-VIEW is turned off.

DIMMER FUNCTION

- When the I-VIEW is on, press and hold the power button to decrease/increase the brightness of the light.
- The light will flash when the minimum/maximum brightness is reached.
- The I-VIEW will remember the brightness level when turned off.

IR SENSOR

- To activate the Infrared on/off sensor, press the "Wireless" button.
- The green LEDS will turn on when the sensor is activated.



To turn the I-VIEW on/off with the IR Sensor, wave a hand in front of the I-VIEW.

SENSOR FUNCTION €1 x2

TEMPERATURE PROTECTION:

- The I-VIEW has a battery temperature monitor.
- In case of overtemperature the brightness will be lowered or turned off until a safe battery temperature is reached.
- Charging will be suspended in case of over temperature.
- All 4 LEDs will flash 5 times if the I-VIEW is turned off because of temperature.



Discarded electrical products must not be disposed of together with household waste. Please use recycling facilities. Ask your local authority or retailer for advice on recycling.

- The battery must be removed from the device before it is broken up
- The device must be disconnected from the mains when the battery is removed
- Please dispose of the battery safely

